

RI-ENERGYFLOW-STACK

All-in-one Hybrid Modular Inverter
& Battery Solution for Solar and
Energy Storage



User Manual

Installation, Operation & Maintenance Manual

Table of Contents

1 ABOUT THIS MANUAL	3
1.1 Purpose	3
1.2 Intended Audience	3
1.3 Conventions	4
1.4 Change History	4
2 SAFETY INSTRUCTIONS	5
2.1 Limitation of Liability	5
2.2 Warning Signs	6
2.3 Battery Safety	7
2.4 Before Installation	10
2.5 Installation Safety	12
2.6 Operation Safety	14
2.7 Maintenance Safety	17
2.8 Disposal Safety	18
3 PRODUCT INTRODUCTION	19
3.1 Features	19
3.2 Delivery Scope	19
3.3 Model	20
3.4 Inverter Appearance	20
3.5 External ports on the inverter	21
3.6 Battery Pack Appearance	22
3.7 Battery port information	22
3.8 Energy Management System (EMS)	24
3.9 Parallel System	24
3.10 Scenarios	25
3.11 Wiring Diagram	29
3.12 System States	31
3.13 Working Modes	32
4 INSTALLATION	34
4.1 Checking the Package	34
4.2 Preparing Tools and Instruments	37
4.3 Installation Position Requirements	38
4.4 Installing the System	41
4.5 Installing a Parallel System	59
5 COMMISSIONING	63
5.1 Checking Before Power-on	63
5.2 Powering On	63
5.3 Setting Common Parameters for the System	64
5.4 Checking the Settings	65
5.5 Powering off	66

6 SYSTEM OPERATION	66
6.1 Download APP and registration	66
6.2 Local Mode.....	74
6.3 Operating Battery Packs	99
7 RESIDENTIAL ESS THIRD-PARTY EMS TECHNICAL SPECIFICATION.....	101
7.1 Functional Description.....	101
7.2 Applicable Models	101
7.3 Configuration Methods	101
7.4 Inverter Settings	102
8 MAINTENANCE	105
8.1 Inspection Checklist for Users.....	105
8.2 Inspection Checklist for Professional Personnel	106
8.3 Troubleshooting	106
9 STORING AND RECHARGING BATTERIES	117
9.1 Storage Environment Requirements	117
9.2 Interval for Recharging Batteries	117
9.3 Recharging a Battery	118
10 LIMITED WARRANTY	119
10.1 What This Warranty Covers.....	119
10.2 How to Obtain Warranty Service	119
10.3 Customer Responsibility for Warranty Service	119
10.4 Limitation of Liability	120
11 EMERGENCY PROCEDURE	121
11.1 General Handling	121
11.2 Potential Emergencies	121
11.3 Emergency Handling Plan.....	123
12 DISPOSAL	123
13 SPECIFICATIONS	124
13.1 Hybrid Inverter.....	124
13.2 Battery Terminal Input /Output.....	125
13.3 PV Input	125
13.4 Grid Terminal Input / Output.....	126
13.5 EPS Load Terminal Output	126
13.6 Battery Pack	127
14 ABBREVIATIONS	128
15 APPENDIX: DEFINITION OF DVC	129

Legal Statement

All material appearing on this manual (“content”) is the property of Rayleigh Instruments Limited (“Rayleigh Instruments”). Distributing, copying, or forwarding any content to a third party or uploading any content to third-party platforms (such as publicly accessible websites) without prior permission of Rayleigh Instruments is expressly prohibited.

Trademarks and Permissions

All other trademarks or registered trademarks are the property of their respective owners.

Software License

Rayleigh Instruments reserves all rights to the firmware and software. You may not use any of the data in the firmware or software for commercial purposes in any way.

Reverse engineering, decompiling, disassembling, adapting, implanting, or other derivative operations on the equipment are prohibited, as are researching the design and implementation of the equipment, obtaining the source code, infringing on intellectual property rights in any way, and disclosing the results of any performance tests.

Disclaimer

Before transporting, storing, installing, using, and/or maintaining the equipment, read this manual, adhere strictly to its prescriptions, and pay attention to the labels on the equipment.

In this manual,

- “Equipment” refers to the hardware products, firmware, software, components, spare parts, and/or services to which this manual relates.
- “You” or “your” refers to an individual or a legal entity transporting, storing, installing, using, and/or maintaining the equipment.

In addition to paying proper attention to content in this manual labelled DANGER, WARNING, CAUTION, and NOTICE, you shall comply with relevant international, national, or regional standards, and industry practices. Rayleigh Instruments shall not be liable for any damages resulting from violations of safety requirements or safety standards for the design, manufacturing, and use of the equipment.

Rayleigh Instruments is not responsible for damage, personal injuries, death, and/or loss of or damage to property caused by use outside the scope of the conditions, technical specifications, or instructions provided in this manual.

Transport, storage, installation, use, maintenance, and all other operations shall comply with applicable laws and regulations, standards, and specifications.

Rayleigh Instruments shall bear no liability in any of the following circumstances:

- The equipment is damaged due to earthquakes, floods, volcanic eruptions, mudslides, lightning strikes, fires, wars or armed conflicts, typhoons, hurricanes, tornadoes, extreme weather, or other force majeure events.
- The equipment is used outside the scope of the conditions, technical specifications, or instructions provided in this manual.
- Installation and/or use do not comply with relevant international, national, or regional standards or regulations.
- The equipment is installed or operated by unqualified personnel.
- The equipment is operated in a manner not in accordance with the prescriptions of the instruction manual and safety labels.
- The equipment and/or software code is disassembled and/or modified without the permission of Rayleigh Instruments.
- The equipment is damaged while being transported by you or a third party commissioned by you.
- The equipment is stored in conditions that do not meet the standards specified in this manual.
- In the course of operating or maintaining the equipment, you use your own materials and tools that do not meet the requirements of local laws, regulations, and standards.
- Damage is caused by you or a third party through negligence, willful misconduct, gross negligence, or mishandling, or for other reasons not attributable to Rayleigh Instruments.

1 About This Manual

This manual contains important information on the transport, storage, installation, use, and maintenance of the equipment. Read this manual carefully before operation. You must use the equipment strictly in accordance with the instructions in this manual to prevent damage or loss to the equipment, persons, and/or property. Keep this manual for future reference.

1.1 Purpose

This manual is intended as:

- An introduction to a RI-ENERGYFLOW-STACK single -phase hybrid inverter and the battery pack.
- An installation and maintenance guide for qualified personnel and technicians working with the hybrid inverters.
- An operating guide for qualified personnel, technicians, and users of the energy management system (EMS) integrated in the hybrid inverter.

This manual does not include information on all the components in a photovoltaic system. For more information, visit the websites of the component manufacturers.

1.2 Intended Audience

The intended audience of this manual is:

- The qualified professional personnel and technicians who install, operate, and maintain residential photovoltaic energy storage systems that include a RI-ENERGYFLOW-STACK hybrid inverter, and/or battery pack.
- Users who need to view inverter parameters.
- System integration solution providers.

1.3 Conventions

The following symbols are used in this manual to highlight important information.

 DANGER	Indicates a hazardous situation that, if not avoided, will result in death or severe injury.
 WARNING	Indicates a hazardous situation that, if not avoided, could result in death or severe injury.
 CAUTION	Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.
NOTICE	Indicates information that is considered important but is not hazard related, typically used for activities that result in property damage, but no personal injury.
	Indicates an important tip that leads to the best results, but not safety or damage related.

1.4 Change History

Here is the change history of this manual.

Version	Date	Changes
1.0	2026-02	• Initial release.

2 Safety Instructions

All the safety instructions in this section help you transport, store, install, use, and maintain the equipment safely, so be sure to read and follow them. In addition to these safety instructions, you must comply with the requirements of international, national, or regional standards and regulations, and you are encouraged to follow industry best practices.

The equipment must be transported, installed, and maintained by trained professionals who fully understand how the equipment works, have sufficient training and experience in operating the equipment, and know the possible dangers and their levels. Trained personnel are those who have received relevant technical and safety training and have relevant experience. They know the possible dangers they may face when operating the equipment and how to take steps to minimize the dangers to themselves and others.

2.1 Limitation of Liability

Rayleigh Instruments is not responsible, directly or indirectly, for any damage to the equipment or loss of property caused by the following:

- Disassembling and/or modifying the equipment, replacing parts, or modifying the software code without the permission of the manufacturer.
- Altering, repairing, and erasing serial numbers or seals by technicians not certified by the manufacturer.
- Installation and/or operation of the equipment by unqualified personnel.
- Installing the inverter in any way that does not comply with standards or regulations.
- Failure to comply with local safety regulations. For example, in Germany, equipment must comply with VDE certification and in Australia it must comply with SAA certification.
- Operation of the equipment in an environment with insufficient ventilation.
- Use not in accordance with the instruction manual, technical specifications, and/or any other instruction provided.
- Use of your own materials and tools that do not meet the requirements of local laws, regulations, and standards.
- Failure to follow standard maintenance procedures.
- Earthquakes, floods, volcanic eruptions, mudslides, lightning strikes, fires, wars, armed conflicts, typhoons, hurricanes, tornadoes, extreme weather, or other force majeure events.

Additionally, Rayleigh Instruments is not responsible, directly or indirectly, for:


- Damage sustained during transportation, including paint scratches caused by friction inside the package during transportation, and damage sustained while being transported by you or a third party commissioned by you. You must file claims with the shipping or insurance company when the container and/or the package is unloaded and the damage is confirmed.

- Any other damage caused by you or a third party through negligence, willful misconduct, or mishandling, or for other reasons not attributable to Rayleigh Instruments.

2.2 Warning Signs

The warning signs and nameplates attached to the equipment contain important information to guide you in safe use of the equipment. DO NOT remove, obscure, or damage these signs. Make sure that these signs are always intact and fixed in their correct positions. If a warning sign is damaged, contact the manufacturer and have it replaced immediately by certified technicians.

You can see these warning signs attached to the equipment.

	Indicates a hazardous situation that, if not avoided, can result in death or severe injury!
	Indicates that the inverter should NOT be touched or used for at least five minutes after it is turned off or disconnected, in order to prevent electric shock or personal injury.
	Indicates a hot surface. Contact can cause burns.
	Indicates that you should read the user manual for instructions.

WARNING

After the equipment is unpacked,

- Check all the warning signs and nameplates on the equipment.
- If you find any damages to the warning signs and/or nameplates on the equipment, contact the manufacturer immediately and DO NOT install the equipment.

WARNING

Before disposal, make sure that all warning signs and nameplates are clearly visible and are not removed or obscured.

WARNING

When you instruct others in use of the equipment, and maintain and/or repair the equipment, follow these instructions to prevent inappropriate use or accidents caused by uninvolved persons:

- Place clear signs at the front and rear-level switches to prevent accidents caused by inappropriate switching.
- Place a warning sign or safety caution tape around the operating area.

2.3 Battery Safety

A rechargeable lithium-ion phosphate battery is used in the equipment. The battery complies with the provisions of “United Nations Recommendations on the Transport of Dangerous Goods, Manual of Tests and Criteria, Part III, Section 38.3”.

Rayleigh Instruments shall not be responsible for:

- Damages to the battery caused by earthquakes, floods, volcanic eruptions, mudslides, lightning strikes, fires, wars, armed conflicts, typhoons, hurricanes, tornadoes, extreme weather, or other force majeure events.
- Direct damage caused by operation of the equipment in environments other than the intended operating environment. Indicators of inappropriate environments include, but are not limited to, excessively high or low operating temperatures, instability of the power Grid, and frequent power outages.
- Damage, leakage, and/or rupture caused by inappropriate operation or failure to connect the battery pack in accordance with requirements.
- Damage caused by over-discharge of the battery due to the failure of operating personnel to promptly power up the battery after it has been connected to the system.
- Damage caused by your failure to accept the battery in time after installation.
- Damage caused by inappropriate parameters that you set.
- Accelerated battery capacity degradation caused by mixing of batteries, including, but not limited to, the mixing of batteries of different brands and mixing of batteries with different rated capacities.
- Battery damage caused by storing the battery in an unintended environment, such as in a humid, rain-prone environment.
- Loss of capacity or irreversible damage to the battery caused over-storage without recharging the battery in a timely manner.
- Damage caused by your or a third party's failure to follow the requirements specified by the manufacturer, including, but not limited to, unauthorised relocation and installation of the battery packs.

Rayleigh Instruments shall not be responsible for damage caused by:

- Frequent over-discharge of batteries caused by your inappropriate maintenance, on-site expansion, or long-term failure to fully charge.
- Lack of appropriate maintenance in accordance with the operating manual. Such battery maintenance should include, but is not limited to, regular checks of the battery terminal screws to verify tightness.
- Changing the battery usage scenario without the approval of the manufacturer.
- Unapproved connection of additional loads to the battery.
- Batteries exceeding the maximum storage life.
- Batteries exceeding the warranty period. Such batteries can pose hazards and it is not recommended that you continue to use them.

2.3.1 General Instructions

The chemical substances inside the battery are well sealed, so there is no physical danger of fire or explosion or chemical danger of hazardous material leakage at normal temperatures and pressure levels during handling. If the battery pack is exposed to fire, mechanical shock, decomposition, or increased electrical stress due to misuse, then leakage, release of harmful substances, and/or explosion can occur. The released substances can irritate the eyes, skin, and throat.

DANGER

- Only trained professionals are permitted to handle leaking batteries.
- When handling leaking batteries, personnel must wear goggles, rubber gloves, gas masks, and protective clothing.
- When handling leaking batteries, personnel must first disconnect the equipment and then remove the leaking batteries.
- Batteries should be protected from the following:
 - Short circuit caused by live line maintenance or by shorting the positive and negative terminals of the battery.
 - Exposure to high temperature or heating equipment such as direct sunlight, ignition sources, transformers, or heaters.
 - Squeezing by an external force or immersion in water or other liquids.
 - Over-charging or forced over-discharging.
 - Exposing battery terminals to other metal objects.
 - The use of incorrect battery types.

WARNING

- Batteries should be protected from the following:
 - Malfunctions or short circuits caused by liquid entering the battery. Therefore, DO NOT install the battery pack under air conditioning outlets, ventilation vents, machine room outlet windows, water pipes, and other locations prone to water leakage.
- Inverted, sideways, tilted, or stacked placement.
- False connection of fastening screws of the copper row and/or the cable, which can cause excessive voltage drop or the generation of a large amount of heat at higher current, which could burn the battery.

2.3.2 Maintenance of Battery Packs

DANGER

- DO NOT perform live line maintenance on the batteries to prevent short circuit.
- Use the specified type of battery during replacement.

WARNING

- Do a regular check on the fastening screws of copper rows and/or cables. Make sure that they are tightened and free of rust, corrosion, or other foreign objects. If they are not, clean them.

2.3.3 Disposal of Battery Packs

WARNING

- Before disposal, completely discharge the battery and consume the lithium metal inside the battery.
- DO NOT treat unwanted batteries as ordinary waste.
- DO NOT throw the battery pack into fire or place them in high temperature.
- DO NOT dissect, pierce, or crush the batteries.
- If a battery pack is deformed, broken, or leaking, discard it immediately regardless of how long it has been in storage.

2.4 Before Installation

DANGER

- Follow the safety instructions in this manual to prevent personal injury and/or property damage.
- During transportation, a certified ABC fire extinguisher with a capacity of at least 2 kg must be with the equipment.
- Smoking is not permitted on or near the vehicle while loading or unloading.
- Before installation, make sure that the equipment is free of any electrical connections.
- Make sure that no water pipes are inside the wall on which the system is to be mounted.
- To prevent possible electric shock, make sure that the inverter is not damaged and that the inverter and all switches connected to it are set to the “OFF” position.
- Before installation, use a properly calibrated voltage meter to test the inverter to prevent personal injury or damage caused by a life-threatening voltage.
- The PV string exposed to sunlight can generate high voltage. Do these to prevent personal injury:
 - The operator must wear personal protective equipment before electrical connection.
 - Before touching DC cables, use a measuring device to make sure that the cables are not energized.
 - Read the safety instructions attached to the PV string and its manuals.
 - DO NOT connect the inverter to a PV string that requires positive or negative grounding.



WARNING

- DO NOT transport equipment in severe weather such as lightning, rain, snow, or winds of force 6 or higher.
- If there is a fire, evacuate the building or equipment area and ring the fire alarm. DO NOT enter a burning building or equipment area.
- Choose an appropriate and safe place to install the equipment. This place must meet these requirements:
 - Temperature: For the inverter and battery pack. See [Specifications](#).
 - Relative humidity: 0–95% (No condensation).
 - NO flammable or explosive materials.
 - NOT accessible to children.
 - NO salt hazards.
 - Sheltered from direct sunlight or severe weather.
 - NOT subject to strong vibration or electromagnetic fields.
 - Well ventilated
 - NOT a living area.
- A distance of at least 30 mm must be maintained between the cable and a heat generating device or the periphery of a heat source area to prevent deterioration and/or breakage of the cable insulation caused by high temperature.
- DO NOT install the equipment that is infiltrated by moisture.
- DO NOT install the equipment with damaged enclosure and exposed to moisture.



CAUTION

- Only qualified personnel are permitted to transport the equipment.
- Loading, unloading, installation, removal, and transportation of inverters and battery packs must be accomplished by two or more persons to prevent personal injury caused by accidental falling equipment.
- If lifting tools are used to lift the equipment, make sure that no one passes or stays under the equipment.

NOTICE

- Before installation, do a regular check and maintenance on the tools.
-

2.5 Installation Safety



- To avoid personal injury caused by the high voltage inside the equipment:
 - Use special insulated tools for wiring.
 - Read the warning signs on the equipment and follow their instructions.
 - Follow the safety instructions in this manual and other documents provided.
 - Only trained professionals are permitted to install the equipment.
 - Only qualified personnel are permitted to disassemble the safety features and to service the equipment.
 - Only the personnel who have the special operation qualification required by national or local authorities are permitted to work in special scenarios such as electrical operation, work at heights, and operation of special equipment.
 - Only Rayleigh Instruments-approved professional personnel are permitted to replace the equipment or spare parts (including software).
 - DO NOT power up the equipment before the installation is completed and confirmed by trained professionals.
 - Avoid direct contact with the power supply equipment, as well as indirect contact through wet objects. Prevent other conductors from coming into contact with the power supply equipment. Measure the voltage at the point of contact before you touch any conductor surface or terminal, so as to avoid electric shock.
 - Use appropriate measuring tools to make sure that the electrical parameters of the equipment meet the requirements. To prevent electric arcs or shocks, make sure that the connection and use of the equipment comply with the specifications.
-



WARNING

- DO NOT install equipment in severe weather such as lightning, rain, snow, or winds of force 6 or higher.
- If there is a fire, evacuate the building or equipment area and ring the fire alarm, or call the emergency services. DO NOT enter a burning building or equipment area.
- It is recommended that you install the inverter vertically, not inverted, horizontal, tilted forward or backward, excessively tilted, or tilted sideways.
- When tightening screws or bolts on products or terminals with tools, tighten to the specified torque to prevent damage to the equipment. The manufacturer shall not be responsible for such damage.
- DO NOT touch the equipment surface when the equipment is in operation. The housing gets hot, and touching it can result in burns.
- The cables used in the PV system must be of the right size, firmly connected, and well insulated.
- Before connecting the DC connector to the inverter, check the positive and negative terminals of the PV string and make sure that no error occurs before inserting the DC connector into the DC terminal.
- During the installation of the inverter, make sure that neither the positive nor the negative terminal of the PV string is shorted to ground, to prevent damage caused by AC/DC short circuit of the inverter.



CAUTION

- To prevent uninvolved persons from approaching the equipment, place highly visible warning signs or set up safety caution tape around the equipment.
- DO NOT remove the equipment protection.
- DO NOT ignore the danger, warning, caution, and notice text in the manuals and on the equipment.

NOTICE

- The wiring process must follow the regulations of the local Grid and the safety instructions for the PV string.
-

2.6 Operation Safety



DANGER

- Follow the safety instructions in this manual to prevent personal injury and/or property damage.
- The person who operates the equipment must have necessary knowledge of the equipment, including the equipment components and how they work.
- The person who operates the equipment must have necessary knowledge of this manual.
- Only qualified personnel are permitted to disassemble the safety features and to service the equipment.
- Keep persons other than those operating the equipment away from the equipment.
- DO NOT operate the equipment in an environment where explosions can occur, or where the relative humidity is high.
- When the equipment is in operation,
 - DO NOT open the inverter and the battery packs.
 - DO NOT wipe the equipment with a wet cloth.
 - DO NOT touch the housing of the equipment.
 - DO NOT plug or unplug connectors on the inverter.
 - To avoid electric shock, DO NOT touch any terminals of the inverter.
 - To avoid electric shock, DO NOT disassemble any parts of the inverter.
 - To avoid burns, DO NOT touch any hot parts of the inverter, such as radiator.
 - To avoid electric shock, DO NOT connect or disconnect a PV string or a component of a PV string.
- To avoid fatal electric shock, DO NOT touch the DC conductors or energized electrical parts of the inverter. When PV arrays are exposed to sunlight, they can generate life-threatening DC voltage. This voltage can be present in DC conductors and in the energized electrical parts of the inverter.
- To avoid electric shocks and burns caused by possible arcs, DO NOT disconnect the DC connector from the inverter under load.
- Before operating the inverter or the battery packs, disconnect the inverter from all voltage sources as described in this manual.
- DO NOT touch uninsulated cable ends.

-
- To prevent chemical burns caused by leakage of electrolyte or toxic gases from a damaged battery, operate the battery packs in accordance with the standard procedure. When the battery packs are operated in a standard manner, no leakage of electrolyte or generation of toxic gases can occur. However, if the battery packs are damaged or malfunction, it can leak electrolyte or generate toxic gases.



WARNING

- DO NOT operate equipment in severe weather such as lightning, rain, snow, or winds of force 6 or higher.
- DO NOT touch the equipment with wet hands.
- DO NOT put any heavy objects on the top of the equipment.
- DO NOT damage the equipment with sharp objects.



WARNING

External protective earthing terminal shall meet at least one of the following requirements:

- When the cross-sectional area of the earthing cable is $\geq 10\text{mm}^2$ (copper) or $\geq 16\text{mm}^2$ (aluminum), it is recommended that both the external protective earthing terminal and the AC side earthing terminal are grounded.
- When the cross-sectional area of the earthing cable is $< 10\text{mm}^2$ (copper) or $< 16\text{mm}^2$ (aluminum), ****ensure that**** both the external protective earthing terminal and the AC side earthing terminal are grounded.

If alternative earthing methods comply with local standards and relevant safety regulations, the connection may be performed according to such standards and regulations. Our company shall not be held liable for any consequences that may arise therefrom.



CAUTION

- To prevent uninvolved persons from approaching the equipment, place highly visible warning signs or set up safety caution tape around the equipment.
- DO NOT move the inverter when it is connected to the battery packs.
- Secure the inverter to prevent tilting.
- During the operation of the equipment, if any risks are found that may lead to personal injury or equipment damage, stop the operation immediately, report to the person in charge, and take effective steps.
- During the operation of the inverter, make sure that neither the positive nor the negative terminal of the PV string is shorted to ground, to prevent damage caused by AC/DC short circuit of the inverter.

NOTICE

- In the event of exposure to the electrolyte, immediately flush the affected area with water and seek immediate medical attention.
-

2.7 Maintenance Safety



DANGER

- Follow the safety instructions in this manual to prevent personal injury and/or property damage.
- Only trained professionals are permitted to maintain the equipment.
- Only qualified personnel are permitted to disassemble the safety features and to service the equipment.
- Keep persons other than those operating the equipment away from the equipment.
- Wear personal protective equipment (PPE), including protective gloves and protective shoes.
- DO NOT begin maintenance work on the equipment until it is turned off and fully discharged.
- Before maintenance, disconnect the AC circuit breaker from the Grid and check the inverter status. If all the inverter indicator lights are off, do nothing and disconnect the DC switch at night. If the inverter indicator is on, disconnect the DC switch directly.
- After the inverter is powered down for five minutes, use testing equipment to check the voltage of the bus capacitor and of the capacitors in the battery terminal input and make sure that there is no voltage.
- To avoid burns, DO NOT operate the equipment immediately after shutdown. After the equipment cools down, wear protective gloves to operate the equipment.



WARNING

- DO NOT maintain equipment in severe weather such as lightning, rain, snow, or winds of force 6 or higher.
- To avoid electric shock, DO NOT touch the power Grid or the contacts and terminals inside the equipment that are connected to the Grid.
- Use a standard voltmeter to check the Grid. DO NOT touch the Grid before you make sure that there is not voltage.
- To prevent or to minimize potential damage caused by moisture, DO NOT repair or maintain the equipment in a wet environment.



CAUTION

- To prevent uninvolved persons from approaching the equipment, place highly visible warning signs or set up safety caution tape around the equipment.

NOTICE

- If the paint on the inverter housing falls off or rust appears, repair it in a timely manner. Otherwise, the use of the inverter may be affected.
 - To avoid damaging the inverter, DO NOT use cleaning agents to clean the inverter. The manufacturer shall not be responsible for such damages.
 - DO NOT open the inverter (excluding the cable box) and replace the components inside without the permission of the manufacturer.
-

2.8 Disposal Safety



DANGER

- Only trained professionals are permitted to discard the equipment.
-



WARNING

- Before disposal, make sure that all warning signs and nameplates are clearly visible and have not been removed or obscured.
 - To prevent property damage and personal injury, dispose of equipment in accordance with local regulations and standards.
-

3 Product Introduction

3.1 Features

The RI-ENERGYFLOW-STACK is a residential photovoltaic storage system that is composed of a power control module and an extendable battery pack. It stores and releases electrical energy according to the inverter management system requirements. Rayleigh Instruments provides a photovoltaic storage-monitoring platform to monitor and control electricity generation and storage of the RI-ENERGYFLOW-STACK. Power generation, consumption, and storage can be grasped at any time and any place, and the information can be monitored and controlled remotely. The RI-ENERGYFLOW-STACK comes with an integrated energy management system (EMS). This system enables the inverter to run off-Grid or on-Grid and manages energy flow intelligently so that the system can operate economically.

3.2 Delivery Scope




Figure 3-1 RI-ENERGYFLOW-STACK Delivery Scope

- 1 Hybrid inverter (with integrated Energy Management System).
- 2 Battery packs, extendable.
- 3 SOLARMAN, for remote monitoring, available in a web-based portal and an APP. For more information, see Stick Logger Quick Guide.
- 4 Stick logger, to be connected to the inverter. For more information, see Stick Logger Quick Guide.

3.3 Model

3.3.1 Inverter Model

The hybrid inverter model is:


RI-ENERGYFLOW-STACK-3.68kW
RI-ENERGYFLOW-STACK-5.00kW
RI-ENERGYFLOW-STACK-6.00kW

3.3.2 Battery Pack Model

The hybrid inverter model is:

RI-ENERGYPACK-STACK-5.1
RI-ENERGYPACK-STACK-10.2
RI-ENERGYPACK-STACK-15.3
RI-ENERGYPACK-STACK-20.4

3.4 Inverter Appearance



Item	Describe	Item	Describe
1	Left decorative panel	2	LED display panel
3	Right decorative panel	4	Floor stand support

Figure 3-2 the main components exploded diagram in the inverter packaging box

3.5 External ports on the inverter




Figure 3-3 External Interface

Item	Describe	Item	Describe
1	WLAN/4G/LAN (DVC A)	2	DRY contact (DVC A)
3	DRM (DVC A)	4	CT/METER (DVC A)
5	Parallel1 (DVC A)	6	Parallel2 (DVC A)
7	GRID (DVC C)	8	EPS (DVC C)
9	PV SWITCH (DVC C)	10	PV1/PV2 (DVC C)
11	BAT CAN (DVC A)	12	BAT BUTTON (DVC A)
13	BAT connect (DVC C)		




Decisive voltage classification (DVC) identifies the minimum necessary level of protection for the circuit. For more information on the DVC of each port, see [Appendix: Definition of DVC](#).


3.6 Battery Pack Appearance

RI-ENERGYPACK-STACK-5.2

Power button





DC SWITCH



3.7 Battery port information

3.7.1 Battery interface female



Code	Describe
1	Battery-
2	Battery-
3	Chassis ground
4	CANH
5	Activate_5V+
6	Inverter_key+
7	Inverter_Contact+
8	UP_IN+
9	CANL
10	Activate_5V-
11	Inverter_key-
12	Inverter_Contact-
13	UP_IN-
14	Battery+
15	Battery+

3.7.2 Battery interface male




Figure 3-4 Appearance of BP48100P(F)1A-G2

Code	Describe
1	Battery-
2	Battery-
3	Chassis ground
4	CANH
5	Activate_5V+
6	NC
7	NC
8	DO_OP+
9	CANL
10	Activate_5V-
11	NC
12	NC
13	DO_OP-
14	Battery+
15	Battery+

3.8 Energy Management System (EMS)

The inverter incorporates an electric energy management system (EMS) for low-voltage power distribution systems. It is an extended development of the energy management system that complies with the standard specifications of the power distribution system. It is highly automated, easy-to-use, high-performance, and highly reliable. You can turn on Bluetooth or WIFI switch on your mobile phone and then open the SOLARMAN Smart APP to deploy loads, optimize operation, and effectively save power.

3.9 Parallel System

With the RI-ENERGYFLOW-STACK, you can connect up to four inverters of the same model in parallel to build a parallel system. In a parallel system, loads must be connected in parallel on both the on-Grid and EPS sides. Compared with a system installed with one inverter, a parallel system expands the system capacity. For example, the rated power of the on-Grid side of a system installed with one RI-ENERGYFLOW-STACK-6.00kW is 6 kW, but the rated power of the on-Grid side of a parallel system with three RI-ENERGYFLOW-STACK-6.00kW s is 18 kW ($= 3 \times 6 \text{ kW}$). The rated power of the EPS side is calculated in the same way.

To build a parallel system, you must set one inverter as the primary inverter, and others as subordinate inverters. For more information, see [Installing a Parallel System](#).



- In a parallel system, the total Grid power and total load power of each inverter can be viewed through the SOLARMAN Smart APP on a mobile device.
- In a parallel system, for some settings, such as working mode, zero export, and time setting of the PEAK SHIFT mode, you only need to set them in the primary inverter. These settings in the subordinate inverters are to be forced to synchronize with the primary inverter, but the setting values shown on the SOLARMAN Smart APP of the subordinate inverters do not automatically change in synchronization.
- In a parallel system, all settings must be the same for all inverters except for the addresses of the inverters.

3.10 Scenarios

The RI-ENERGYFLOW-STACK can be used in both a DC-coupling system and an AC- coupling system.

3.10.1 DC-coupling System

In a DC-coupling system, the DC electricity generated by the PV panels is directly sent to and stored in the batteries through the inverter. A DC-coupling system is ideal for a new on- and off-Grid solar+storage system installation.




Figure 3-5 DC-coupling System

Here is the single line diagram of a DC-coupling system.




Figure 3-6 Single Line Diagram, DC-coupling System

3.10.2 AC-coupling System

In an AC-coupling system, DC electricity flows from PV panels to the inverter, the AC electricity from the inverter flows to the household loads or other inverters to transform the AC electricity back to DC electricity, and then store it in the batteries. An AC-coupling system is ideal for retrofit.

The RI-ENERGYFLOW-STACK supports two AC-coupling system schemas.

If you already have a PV inverter and now want to add an energy storage system to the inverter, but no PV panel is available for connection, you can use AC-coupling system Schema 1.




Figure 3-7 AC-coupling System, Schema 1




Figure 3-8 Single Line Diagram, AC-coupling System Schema 1

If you already have a PV inverter, and want to add an energy storage system to the inverter, and a PV panel is available for connection, you can use Schema 2 of AC-coupling system.




Figure 3-9 AC-coupling System, Schema 2

Here is the single line diagram of an AC-coupling system Schema 2.




Figure 3-10 Single Line Diagram, AC-coupling System Schema 2

3.11 Wiring Diagram

NOTICE

Make sure that the grounding resistance is less than 10 Ω .

In Australia, New Zealand, and South Africa, direct connection of the N cable and the PE cable in the distribution box is necessary, as shown in [Figure 3-11](#)




Figure 3-11 Wiring for Australia, New Zealand, and South Africa

Outside Australia, New Zealand, and South Africa, the N cable and the PE cable in the distribution box must be wired separately, as shown in [Figure 3-12](#).



Make sure that the grounding of the EPS load is correct and tightened. Otherwise, during a Grid failure, the EPS may not function normally.




Figure 3-12 Wiring Outside Australia, New Zealand, and South Africa

The battery power and signal connectors are in blind-inserted mode, so the communication is automatically connected after the battery packs and the inverter are assembled.

3.12 System States

3.12.1 Inverter States

The inverter can be in six states shown in [Table 3-2](#).




Table 3-2 Inverter States

Icons	Implication	Color	Status	Describe
A	PV Indicator	Green	On	PV operating normally
			Flashing	PV connected but not operating
			Off	PV not connected
B	Communication Indicator	Green	On	Monitoring backend connected and communication normal
			Off	Monitoring module not connected or communication abnormal
C	Grid Indicator	Green	On	System in On-Grid operation mode
			Flashing	System in bypass mode
			Off	System in initialization, standby, off-Grid, fault, commissioning, or upgrade mode
D	Off-Grid Indicator	Green	On	System in off-Grid PV charging mode

			Off	PV off-Grid charging not in progress
E	Fault Indicator	Red	On	System fault
			Off	
F	Battery Indicator	Green	On	Battery operating normally
			Flashing	Battery abnormal (alarm or BMS communication abnormal)
			Off	Battery shutdown or battery disconnected
F	Battery SOC Indicator (Flashing during charging)	Green	F5: 5/5	≥80%
			F4: 4/5	≥60%
			F3: 3/5	≥40%
			F2: 2/5	≥20%
			F1: 1/5	≥5%
			0	<5%



For more information about the error codes, see [Error Codes of the System](#) and [Alarm Codes of the System](#).

3.12.2 Battery Pack States

A battery pack can be in five states: OFF, NORMAL, ALARM, FAULT, and PROTECTION. For more information, see [Indicator Lights and States](#).

3.13 Working Modes

The RI-ENERGYFLOW-STACK supports three working modes: SELF CONSUME, BAT PRIORITY, and PEAK SHIFT. You can choose a working mode through the integrated EMS. For more information, see the [WORK MODE](#) subsection under [Scene setting](#).

3.13.1 SELF CONSUME

In SELF CONSUME mode, the electricity generated by the PV panels is consumed in this order:

Step 1. Supplies electricity for household use.

Step 2. Stores the excess electricity in batteries.

Step 3. Pushes the excess electricity onto the local power Grid.

When the sun goes down, the household power supply is automatically switched to the batteries. If the power supply from the batteries is not sufficient, power is

sourced from the local power Grid.

3.13.2 PRIORITY

In **BAT PRIORITY** mode, the batteries are only used as EPS. When the Grid fails, the household load is powered by the batteries. When the Grid is working, the household load is powered by the Grid, not by the batteries. The PV panels or the local power Grid send electricity to the batteries, where it is stored until needed.

3.13.3 PEAK SHIFT

In PEAK SHIFT mode, you can determine the charging and discharging time of the battery yourself, and if you enabling the peak shift power control, you can set the peak power and valley power of the load power.

4 Installation

With the RI-ENERGYFLOW-STACK, you can install a PV energy storage system using either of two schemas:

- Install one hybrid inverter and one, two, three, or four battery packs.
- Install a parallel system with multiple hybrid inverters of the same model, each with its own battery packs, connected in parallel. For more information, see [Installing a Parallel System](#).

Follow the steps in Figure 4-1 to install a PV energy storage system with an RI-ENERGYFLOW-STACK.




Figure 4-1 Installation Procedure

DANGER

Only trained professionals are permitted to install the system.
Two trained professionals are necessary to carry out installation.


4.1 Checking the Package

Open the package, make an inventory of its contents, and make sure that all hybrid inverter and battery pack components are present.

WARNING

Before opening the package, make sure that the box is not damaged.





4.1.1 Hybrid Inverter Components













Item	Quantity	Description	Item	Quantity	Description
A	1	Inverter (packed and assembled with base)	B	1	Base (must be removed from inverter bottom immediately after unpacking)
C	2	Mounting bracket	D	2	PV terminals: 2x positive, 2x negative
E	6 sets	M4x12 Bolt	F	1	CT
G	1	AC EPS connector	H	1	AC Grid connector
I	1	WIFI Connector	J	1 set	2 screws, 2 rubber sleeves, 2 gasket (base and wall bracket)
K	1	RJ45 Connector	L	1	WIFI+BLE Stick
M	1	PV connector tool	N	1	User manual, Warranty card, Certificate of quality card
O	1	RI-D100-CT Energy Meter (optional)	P	1	Test report
Q	1	CT Connector	R	2	OT terminals
S	1	Positional Punch card	T	1	RS485 Communication Cable (10 m)

4.1.2 Battery pack Components

A battery pack delivery includes the following.

		
M5*12:8pcs	ST6.3*50:2pcs D10*50:2pcs	M6 Gasket:2pcs
		
M4*12:2pcs	Mounting Kit-Wall:2pcs	Mounting Kit-Battery:2pcs
 Mechanical cover*2		

4.2 Preparing Tools and Instruments

		
Protective Goggles	Protective Gloves	Protective Mask
		
Protective Shoes	Wire Clamp	Cable Crimper
		
φ10mm Power Drill	Flat-head Screwdriver	Torque Wrench
		
Cross Screwdriver	Multi-meter	Rubber Mallet
		
Leveling Instrument	Tape Measure	Marker Pen
		
Wire Stripper	ON GRID Wire (Twin & Earth 4 mm ²)	EPS Wire (10 AWG or 4 mm ² ,)
	PV Wire (12 AWG or 4 mm ² , max. Voltage 1,000 V)	

4.3 Installation Position Requirements

The RI-ENERGYFLOW-STACK energy storage system can be installed indoors or outdoors, but the position for installation must meet these requirements:

- Sufficient space for personnel to install and maintain the equipment and to observe the LED indicator light status on the hybrid inverter.
- Ambient temperature: For the inverter and battery pack. See [Specifications](#).
- Relative humidity: 0–95% (No condensation).
- Level floor - not sloped.
- Sheltered from direct sunlight or severe weather.
- Well ventilated
- NOT near flammable or explosive materials.
- NOT exposed to salt hazards.
- NOT subject to strong vibration or electromagnetic fields.
- NOT a habitable room, as defined in AS/NZS 3000
- NOT accessible to children.



The energy storage system needs to keep a certain safe distance (>1m) from the surrounding doors, windows, escape routes and other systems.

4.3.1 Restrictions

DO NOT install the system in these locations:

- Habitable rooms, as defined in AS/NZS 3000.
- Ceiling cavities or wall cavities
- On a roof.
- Underneath staircases or passageways.
- Areas where relative humidity and condensation exceed 95%.
- Places exposed to salty air.
- Earthquake zones, unless additional safety measures have been taken.
- Places at more than 4,000 meters above sea level.
- Places in direct sunlight or places where the ambient temperature varies a lot.
- Places with flammable materials and gases or where explosions may occur.
- Locations where the installation of panels is restricted by AS/NZS 3000.
- Within 600 mm of any heat source, for example, hot water unit, gas heater, air conditioning unit, or any other equipment.
- Hazardous areas with insufficient distance from gas cylinders or gas relief valves as defined in AS/NZS 3000.

The following safety guidelines from MCS should be followed.

SAFETY AND COMPONENT LOCATION

All components shall be located so that escape routes from the premises are not impeded.

- Storage batteries shall be located so that a fire in the battery does not compromise protected escape routes.
- All storage battery enclosures, battery rooms, and locations in which battery enclosures are installed, shall have adequate ventilation to prevent overheating during charging operations.

WEIGHT AND ACCESSIBILITY

- All components shall be mounted on surfaces that are structurally sound and can support the weight of all components mounted on them. Both point loading and weight distribution shall be taken into consideration. If there is any doubt whatsoever then a qualified structural engineer shall be consulted.
- The means of wall mounting for converters, batteries and similar components shall comply with the wall-mounting requirements of BS EN 62109-1.
- Where reinforcement of walls and floors is required, the requirements and responsibility for these works shall be identified as part of the Contract.

Storage batteries and other components of the system shall be located so that any installation, commissioning and maintenance operations can be carried out safely, considering the weight of components and any lifting and manual handling operations required.

When the RI-ENERGYFLOW-STACK is installed indoors, make sure that the building structure, room furniture, and appliances do not interfere with the operation and maintenance of the system.

If the RI-ENERGYFLOW-STACK is installed in a corridor, aisle, lobby, or similar area that leads to an emergency exit, at least one meter of space must be allowed for safe egress.

To prevent fire, the wall or structural surface on which the RI-ENERGYFLOW-STACK is mounted must be made of non-combustible material. If the wall or structural surface is not made of non-combustible material, a layer of non-combustible material can be placed between the equipment and the surface.

4.3.2 Clearance Requirements

If the RI-ENERGYFLOW-STACK is mounted on a wall or on a surface that is 300 mm from a wall or structure that separates the equipment from habitable rooms, the distance between the equipment and other structures or objects must be increased. The minimum required clearance is as follows:

- **A** - above the equipment. 3.68kW ≥200mm / 5.00kW ≥350mm / 6.00kW ≥500mm
- **B** - to the equipment sides. 3.68kW ≥250mm / 5.00kW ≥350mm / 6.00kW ≥500mm
- **C** - between two units. 3.68kW ≥300mm / 5.00kW ≥450mm / 6.00kW ≥600mm
- **D** - in front of the equipment. 3.68kW ≥300mm / 5.00kW ≥400mm / 6.00kW ≥500mm




Figure 4-2 Peripheral Clearance Requirements for Installation

NOTICE

- When installing the RI-ENERGYFLOW-STACK, make sure that the distance between the highest point of the equipment and the ground or the mounting platform does not exceed 2.2 meters.

If the distance between the RI-ENERGYFLOW-STACK and the object above it, for example, a ceiling, is less than 500 mm, the surface of the object must be paved with non-combustible material in the form of a circle with a radius of 600 mm around the center of the equipment.



The minimum distance between the RI-ENERGYFLOW-STACK and the object above it must be more than 200 mm.

4.4 Installing the System

Follow the steps in this section to install an RI-ENERGYFLOW-STACK energy storage system with one hybrid inverter.

4.4.1 Mounting the All-in-one system


NOTES

The inverter should only be moved by two persons. One inverter weighs approximately 25 kg.


Wear protective goggles and a mask to prevent the dust created during drilling from entering the respiratory tract

PROCEDURE


Step 1. Remove the inverter from the carton.




Step 2. Remove the screws in the middle of the decorative side panel.



Step 3. First lift out the decorative side panels upwards, then remove the bottom fixing screws.




Step 4. Place the floor stand support horizontally on the ground.




Step 5. Battery Pack Installation



5-1 Take the battery pack out of the carton and stand it horizontally on the ground , tear off the protective film at the battery interface on both sides of the battery pack, then place the battery pack vertically on the base.



5-2 First, screw the mounting kit-battery onto the battery pack. Then fix the mounting kit wall to the mounting kit battery with screws. Finally, place the battery pack close to the wall for marking, drilling, installing expansion tubes and screws.




4.3U battery pack:



5-3 Install a set of batteries and tighten the screws on both sides at the same time, then continue to stack the next battery module.

Use M4*12 screws to tighten, the screw torque is 2.0N·M When needing to assemble the second battery (and all others), repeat step 5-1 to carry out the installation.

After stacking the battery packs, install mechanical cover on both sides.



Step 6. Install the hybrid inverter

6-1 The disassembled inverter is shown in Figure 2.1.






Figure 2.1

6-2 Use the-Positional Punch card to align the holes on the battery pack, mark the inverter mounting hole positions, and drill using a 10mm drill bit. The drilling depth should exceed 50mm. Place the expansion plug into the hole, then secure the base using ST6.3*50mm screws with a torque of 3.0 Nm.




Step 7. Install the lock wall bracket.

Fix the mounting brackets on both sides of the inverter with screws.




7-1 Stack the inverter on top of the battery pack and secure it using M4*12 screws (fasten into the upper screw holes) with screw a torque of 2.0 Nm.

7-2 Install and secure the wall bracket. After adjusting the wall bracket, fix it using M4*12 screws with a screw torque of 2.0 Nm.



Step 8. Wiring harness installation reference, section 4.4.4

Step 9. Install the side cover. Install the side covers on both sides of the inverter and tighten the screws.



4.4.2 Connecting Battery Packs

The battery power and signal connectors are in blind-inserted mode, so the communication is automatically connected after the battery packs and the inverter are assembled.

4.4.3 Connecting the Inverter and PV Solar Panels

NOTES

- 12 AWG or 4 mm² PV wires are recommended for connection.
- Distinguish the PV polarities and DO NOT reverse the connection.
- Make sure that the input voltage of the PV is within the acceptable input voltage range of the inverter, not higher than 500 V.




DANGER

Make sure that both the PV Switch inside the cable box and the switch on the PV solar panel are in the OFF position.




The scenario where two photovoltaic strings are connected to a single power module requires the model and quantity configuration of the two photovoltaic strings to be consistent. The PV strings should not be grounded to ensure the minimum insulation resistance of the equipment. Before connecting the PV strings to the inverter, the minimum insulation resistance of the PV strings to ground must meet the requirement ($R = \text{maximum input voltage} / 30\text{mA}$). If the insulation resistance value is lower than the above requirement, it will trigger an insulation resistance inverter alarm (high insulation impedance).



PROCEDURE

- Step 1.** Use a wire stripper to remove an approximately 8 mm length of insulation layer of the PV wire.
- Step 2.** Then place the metal connector on top, and use the crimping tool to crimp the metal connector to the wire.
- Step 3.** After the metal conductor is crimped to the wire, place the metal connector into the terminal cover, strain reliever and compression sleeve.
- Step 4.** Plug the metal connector into the connector housing and screw all the components together using the assembly tool. Properly tightening MC4 solar connectors ensures they are water-tight and safe to use. Use a multi-meter to measure the voltage of the PV wire. Make sure that the voltage is lower than 500 V.
- Step 5.** Plug the PV wires into the PV1+, PV1-, PV2+, and PV2- ports in the inverter and ensure they 'snap' home.




4.4.4 Connecting to Grid and Loads



There are three connection ports marked "L", "N", and " $\perp$ " inside the AC connector. The live wire should be connected to the "L" terminal, the neutral wire to the "N" terminal, and the ground wire to the " $\perp$ " terminal. The L and N wires of the AC cable must not be reversed or short-circuited.

The PE wire of the AC cable must be grounded.

The connector cable only supports multi-strand copper wires, and requires riveted tube/pin type terminals. The terminal specifications are selected according to the wire gauge.



NOTICE

- Recommended cables: a 10 AWG or 4-mm² cable for EPS connection and a 8 AWG or 6-mm² cable for ON GRID connection.
- Make sure that the resistance of the wires is lower than 1 Ω .
- Make sure that the grounding resistance, measured between the inverter case and the earth terminal of the distribution box, is less than 10 Ω .



DANGER

Before connection, make sure that the AC current breakers and the LOAD Switch in the distribution box are in the OFF state.



CAUTION

When connecting the wires to the connector, make sure that the phase wires and the earth wire are connected correctly.



CAUTION

Appliances such as air conditioners require sufficient time to equalize refrigerant gases within the circuit, so it takes at least two or three minutes to restart. If power supply is short-circuited and restored within a short period, it can cause damage to these appliances connected to the power supply. Before installing such appliances, make sure that the air conditioner has a time delay function to prevent such damage. In the absence of a time delay function, the inverter triggers an overload fault and cuts off the output to protect your appliances, but internal damage to appliances can sometimes still occur.




The type A or B RCD (≥ 300 mA) must be installed on the EPS port of the system according to local regulations.

An AC circuit breaker of these specifications is recommended:

- ON-GRID connection: 3.68kW - 40A, 5.00kW & 6.00kW - 63A /230 VAC 6 KA
- EPS connection: 32 A/230 VAC 6 KA

PROCEDURE


- Step 1.** Use a wire stripper to remove an appropriate length of the jacket and insulation layer from one wire of the AC cable.
- Step 2.** Disassemble the Grid/Load connectors in the order shown in the diagram.
- Step 3.** Unscrew the swivel nut from the threaded sleeve of the AC connector and insert the wire into the corresponding pins of the AC connector and use a cross screwdriver No.1 (torque 0.8 N.M) to tighten the screws. Then assemble the AC connector components in the order shown in the diagram.
- Step4.** Disassembly and assembly of waterproof cover.
- EPS:** Rotate the locker according to the direction instructed by the marks on the locker.



GRID: Use the unlocking tool to press the connector unlock, then pull the dust cover.



Step 5. Plug the AC connector into the ON GRID or EPS port inside the inverter and tighten the connector.




4.4.5 Connecting a Stick Logger

NOTES

For more information, see Stick Logger Quick Guide.

WARNING

DO NOT hold the logger body to rotate while installing or removing the logger.



NOTICE

DO NOT remove waterproof plug.



PROCEDURE

Step 1. Plug the stick logger into the COM port beside the inverter.




Figure 4-23 Pins of the COM Port

Pin 1: +5V

Pin 2: GND

Pin 3: RS485-A

Pin 4: RS485-B

4.4.6 Connecting External CT

You must connect an external CT or a smart Grid meter between the inverter and the power Grid.

If you want to connect a smart meter, see [Connecting a Smart Meter](#).

If you want to connect an external CT, one CT and a CT& Meter connector are necessary. The connector has six pins, as shown in [Figure 4-24](#). For more information, see Step 2 in the procedure.




Figure 4-24 Pins of CT& Meter Connector

NOTES


The external CT must be installed near the power Grid side **and facing towards the power Grid**. If the power Grid cannot be controlled or remains at 0 W, please check the installation position of the CT.

Table 4-3 Pin Description of CT& METER Port

	PIN	Description
	1	CT+(White)
	2	CT-(Blue)
	3	RS485-A(meter)
	4	RS485-B(meter)
	5	RS485-B (reserve)
	6	RS485-A(reserve)

PROCEDURE

Step 1. Unscrew the nut, sealing, body, and housing of the CT connector.




1 Housing

2 Body


3 Sealing

4 Nut


Step 2. Thread the wires of the CTs through the nut, sealing, and the body, insert them into the pins of the CT& Meter connector, and then tighten the screws.



Step 3. Tighten the nut, sealing, body, and housing of the CT& Meter connector.



Step 4. Plug the CT& Meter connector into the CT port inside the inverter and tighten it.



The arrow on the CT must point toward the power grid.

4.4.7 Connecting a Smart Meter

You must connect an external CT or a smart Grid meter between the inverter and the power Grid.

If you want to connect an external CT, see **Connecting External CT**.

If you want to connect a smart meter, note that only one meter is necessary for each inverter. The meter must be mounted and connected at the Grid transition point (feed-in point) so that it can measure the Grid reference and feed-in power.

To connect a smart meter, a CT & Meter connector is necessary and it must be connected to the CT & Meter port inside the inverter.

NOTES

NOTICE

Currently, only these brands of smart meters are supported: Rayleigh, Easton, YaDa, and CHNT. You can set the smart meter brand in the integrated EMS. For more information, see the [CT OR METER](#) subsection under [Advanced Function](#). The YaDa YDS70-C16 is recommended. The smart meter with CT is already configured. DO NOT change any settings on the smart meter.

PROCEDURE

Step 1. Prepare the communication wires, power cable, and tools for the meter connection.

Step 2. Follow the meter installation manual to install the meter.



The arrow on the CT must point toward the power Grid.




Figure 4-25 Wiring of Smart Meter Connection (Example, YaDa YDS70-C16)

Step 3. Connect the communication line A/B of the meter to pin 3/4 of the CT & Meter connector, and then tighten it.

4.4.8 (Optional) Connecting a DRED or an RRCR

NOTES


The RI-ENERGYFLOW-STACK complies with AS/NZS 4777.2:2015 standard. Its DRM port can be connected to a Demand Response Enabling Device (DRED) in Australia or New Zealand or a Radio Ripple Control Receiver (RRCR) in other areas or countries.



When the Australia or the New Zealand Grid Standard is selected, the DRM port can be enabled to connect a DRED. When other Grid Standards are selected, this port can be enabled to connect an RRCR. For more information about Grid Standards, see [GRID CODE](#).

A DRM connector is necessary for the connection. [Table 4-4](#) shows the pin descriptions of the DRM connector.

Table 4-DRM Connector Pin Descriptions



The RI-ENERGYFLOW-STACK is pre-configured to the following Radio Ripple Control Receiver (RRCR) power levels as shown in [Table 4-5](#).



NOTE

In the “PIN x” columns, “0” means the corresponding relay is closed and “1” means the corresponding relay is opened.

Table 4-5 RRCR Power Level

PIN4	PIN3	PIN2	PIN1	PIN6	Active Power	Cos(Q)
1	0	1	1	1	0%	1
1	1	0	1	1	30%	1
1	1	1	0	1	60%	1
1	1	1	1	0	100%	1
1	1	1	1	1	100%	1
0	X	X	X	X	Standby	1

PROCEDURE

- Step 1.** Make sure that DRM is enabled in the integrated EMS. For more information, see the [DRM ENABLE](#) subsection under [Advanced Function](#).
- Step 2.** Use the DRM connector to connect the DRM port inside the cable box to the external device.

4.4.9 (Optional) Connecting a Generator

If you are using a generator, you can connect the generator to the RI-ENERGYFLOW-STACK energy storage system.




Figure 4-26 Connect a Generator

4.5 Installing a Parallel System

The RI-ENERGYFLOW-STACK supports installation of a parallel system with more than one inverter. A maximum of four inverters can be connected in parallel. For more information, see [Parallel System](#).

4.5.1 Wiring of a Parallel System

Follow these figures for wiring of a parallel system with two, three, or four inverters.



The lengths of the three branch cables from the AC output circuit breaker to the power module must be kept consistent.




Figure 4-28 Wiring of a Parallel System with Two Inverters




Figure 4-29 Wiring of a Parallel System with Four Inverters


- Connecting the Inverter and PV Solar Panels.
- Make sure that all the battery packs are mounted and connected. For more information, see [Mounting the All in One system](#) and [Connecting Battery Packs \(BP48100P \(F\) 1A-G2\)](#).
- Make sure that the Grid and load connections to each inverter are correct. For more information, see [Connecting to Grid and Loads](#).
- Decide which inverter will serve as the primary inverter.



Make sure that only the primary inverter is connected to a CT or an electricity meter. DO NOT connect a CT or an electricity meter to the subordinate inverters. When the number of parallel systems exceeds 2, an electricity meter must be connected. For more information, see [Connecting External CT](#) or [Connecting a Smart Meter](#).

- Make sure that the AC circuit breakers in the distribution box are in the OFF state.
- Prepare the communication network cables required for paralleling for parallel connection.

Table 4-7 Pin Description of the Parallel Ports

	Pin	Description
	1	CAN_H
	2	CAN_L
	3	INV_STATUS_BC
	4	BPSIDE_HOLD_BC
	5	MASTER_SYN_BC
	6, 7, 8	GND

5 Commissioning

Follow the steps in [Figure 5-1](#) to commission the system.




Figure 5-1 Commissioning Procedure

5.1 Checking Before Power-on

Before powering on the system, thoroughly check the installation.

- Step 1.** Make sure that the RI-ENERGYFLOW-STACK is firmly fastened to the mounting panel on the wall.
- Step 2.** Check the electrical connection inside the inverter. Make sure that:
- PV+ and PV- cables are firmly connected and the polarity and voltage are correct.
 - The ON GRID and EPS cables are connected firmly and correctly.
- Step 3.** Check the electrical connection in the inverter. Make sure that:
- The AC circuit breakers for the normal loads are correctly connected.
 - The AC circuit breakers for the EPS loads are correctly connected.
 - Both breakers are in the OFF state.

5.2 Powering On

NOTICE

If PV output voltage is 0 V in sunlight, check the PV connection. Check for reverse connection of the PV and make sure that the circuit connection is correct.

- Step 1.** Turn on the external PV switch.
- Step 2.** Remove the decorative panels on both sides of the inverter.
- Step 3.** First, turn on the circuit breaker switch on the battery pack, and then long-press the battery button next to the inverter (1-3 seconds) until the green light on the battery button lights up.
- Step 4.** On the side of the inverter, turn on the PV Switch.
- Step 5.** In the distribution box, turn on the AC current breaker between the ON GRID port and the Grid.
- Step 6.** In the distribution box, turn on the AC breaker between the EPS port and the EPS loads.



The LOAD Switch is necessary only when an EPS load is connected.

Step 7. Reinstall the decorative panels on both sides of the inverter.

5.3 Setting Common Parameters for the System



In a parallel system, all settings must be the same for all inverters **except for the addresses of the inverters**.

When the energy storage system is powered on:

On the mobile phone, enter the settings page through SOLARMAN Smart to configure the general parameters.

- Step 1.** Set the working mode of the system. For more information, see the [WORK MODE](#) subsection under [Scene setting](#).
- Step 2.** Select the Grid Standard. For more information, see [GRID CODE](#).
- Step 3.** Set the language, date and time of the system. For more information, see [Equipment Basic Information](#).



Figure 5-2 Set Common Parameters

If you want to set more parameters for the system, see [Setting up the System](#).

5.4 Checking the Settings

When the energy storage system is powered on, check the settings of the Battery Pack, PV, and Grid to make sure that the system can work correctly.



To calibrate the SOC of the battery, after the system is installed, the batteries must be charged to 100% SOC once.

Step 1. Follow these steps to check the battery information:

- 1.1 Open the decorative covers on both sides of the inverter



Make sure no red indicator light is ON.

- 1.2 Press the power button(1~3s) until the indicator light of the power button is on.
- 1.3 View Battery Settings and BMS parameters on the SOLARMAN Smart app.
 - Temperature: Depends on the ambient temperature around the system.
 - Voltage: Must be within the 50 V $\pm$ 3 V range.
 - Capacity: The capacity of a battery is 100 AH. When more than one battery pack is connected in parallel, the capacity of the system is 100 AH multiplied by the number of battery packs.

Step 2. After PV input is connected and the PV Switch inside the cable box is turned on, check the information on the **PV1 INPUT** and the **PV2 INPUT** page. For more information, see [Viewing the Current System Information](#).

Step 3. After ON GRID connection is done, check the information on the **GRID VOLT** page. For more information, see [Viewing the Current System Information](#).

5.5 Powering off

WARNING

To prevent damage or personal injury, after the equipment is turned off, **DO NOT begin maintenance work until 5 minutes have passed.**

- Step 1.** If EPS loads are connected, turn off the LOAD Switch In the distribution box and the AC current breaker between the LOAD port and critical loads.
- Step 2.** In the distribution box, turn off the AC current breaker between ON GRID port and the Grid.
- Step 3.** Press the battery buttons (1~3 seconds) until the indicator light of the power button goes out. Finally, turn off the circuit breaker switch on the battery pack.
- Step 4.** On the side of the inverter, turn off the PV Switch.



Precaution:

Please make sure that the battery is not being charged or discharged before performing a shutdown.

6 System Operation

6.1 Download APP and registration

If you are a household user, please scan QR code below to download SOLARMAN Smart APP.



After opening the SOLARMAN Smart App, please Register to ensure normal function of the SOLARMAN Smart App.

Click "**Register**" to continue.

System supports registration by E-mail or Phone number currently. Please follow:

- 1) Set login account. (Phone number and E-mail are supported.)
- 2) Set password. (Password length: 6-50 characters)

11:00 95% 64

<

Register with Email

Angola >

Email Address

☐ By clicking "Next", I confirm that I have read and agree to the [Terms of Use](#) and [Privacy Policy](#)

Next

[Register with Phone Number](#)

Login

If you have an account at SOLARMAN Smart Platform, you can login directly.

10:59 95% 65

China mainland >

demo0@solarman.com

Password

[Forgot your password?](#)

☐ I have read and agree to [Terms of Use](#) and [Privacy Policy](#)

Log in

New user? [Register](#) | [Local Connection](#)

Create a Home


You can create your own Home at "SOLARMAN Smart" to run real-time monitoring. The system will collect and calculate data from associated devices, which enables a full understanding of PV plant running status.

Step 1: Add Now

Click "Start" to create your Home on SOLARMAN Smart .

Notice: If you have already created a Home, you will not see the following page.

And if you wish to create another Home, please click "+" in the upper-right corner and select "Create a Plant".



Step 2: Enter Home Details

Please enter detailed Home information according to your actual situation. The system will create a unique Home for you. In order to calculate plant data precisely, please enter

- Home Name,
- Home Type,
- Grid Type,
- Home Location,
- Other information.

11:11

0 K/s

5G

62%

<

Solar Panels

Is your home using solar panels for electricity generation?



☐ No solar panels installed



☐ Yes, for self-consumption and feed-in to the grid



☐ Yes, only for feed-in to the grid



☐ Yes, only for self-consumption

Next

Add a Logger


After the home is created, you can add a Logger. The Logger collects running data from PV devices and uploads it to the server, which enables a full understanding of PV plant running status and revenue information. Furthermore, SOLARMAN Smart will determine whether the plant is running normally, which can avoid property losses caused by device failure and other reasons.

Step 1: Select a Home

In case you have various Homes, which might cause data corruption, it is recommended to select a Home first before adding a Logger.

Ways to add a Logger :

1) Go to "Home" , click "+" in the upper-right corner, select "Add a Logger", then 「Select a Home」 according to your actual situation.



2) Go to 「Device」 , click "Start" to add a Logger to the target plant.

Step 2: Enter Logger Serial Number

Users can enter the Logger Serial Number manually or click icon in the right to scan SN. SN can be found on the product box. If the product box has been lost, you can find SN on product body.



Network Settings

If the Logger is equipped with a WiFi module, it is required to complete the networking configuration to ensure normal communication.

Go to [Device List] and check if there is "Networking Configuration" button. If not, it means networking configuration is not required.


1. Networking Process

Please use 2.4G network for configuration. 5G network is not supported.

Step 1: Confirm Wi-Fi Info

Please make sure your phone has connected to the right WiFi network and click


"Start"



Step 2: Connect to AP network

Go to Phone Settings-WLAN, find the right "AP_XXXXX" network and click "Go to connect".

Go back to SOLARMAN Smart after your phone has connected to AP network.




Step 3: Auto Configuration

Please wait for a while to complete the configuration. The system will switch to the Configured Page automatically.

When you go back to 「Device List」, the Logger will still be in **Offline** status.

Usually, the data will be updated in 10 mins. Please be patient.






If configuration failure occurs, please check for the following reasons and try it again.

1. Make sure WLAN is ON;
2. Make sure WiFi is normal;
3. Make sure wireless router does not implement a white/black-list;
4. Shorten the distance between the phone and Logger;
5. Try to connect to other Wi-Fi;
6. Remove any special characters (, ; “ ” `) in Wi-Fi network SSID.

6.2 Local Mode

After completing the network configuration, enter the SOLARMAN Smart APP, tap "Device" at the bottom of the screen, select "Local Connection," then scan the QR code on the data logger with your phone, or manually enter the SN number. Once communication between the inverter and the App is established, you can access the Inverter Settings interface.






6.2.1 Battery setting

In this setting, battery parameters can be configured.

- ①. ON Grid/Off Grid discharge depth: Set the maximum depth of discharge (DoD) for both Grid-connected and off-Grid modes. The default is 90%, with an adjustable range of 5% to 90%. Additionally, ensure that the depth of discharge enable setting is activated.
- ②. Bat discharge/charge power setting: Set the battery discharge and charge power percentage. The adjustable range is 0–100%, with a default value of

100%.

- ③. Bat set charge current: Set the battery charging current, adjustable range: 1~125A.
- ④. Wake-up BMS Time: When the battery is in hibernation, the inverter wakes the battery at regular intervals, with a configurable range of 5-300 minutes. At the same time, the wake-up BMS enable setting needs to be activated.
- ⑤. Force charge/discharge Enable: There are three modes: Invalid, Charge, and Discharge.
- ⑥. Charge from Grid Max SOC: After setting the Charge source, the SOC for charging the battery from the Charge source can be configured.



6.2.2 Battery pack parameters

Under this section, you can view the SOC, SOH, cycle count, and cumulative discharge of all connected battery packs.

16:16 11.4

Battery pack parameters
3517727893

ery Setting	Battery pack parameters	Grid Code
Battery pack 1 SOC	54 %	
Battery pack 1 SOH	100 %	
Battery Pack 1 Battery Cycle Count	8	
Battery Pack 1 Cumulative Discharge	49 kWh	
Battery pack 2 SOC	55 %	
Battery pack 2 SOH	100 %	
Battery Pack 2 Battery Cycle Count	11	
Battery Pack 2 Cumulative Discharge	49 kWh	
Battery pack 3 SOC	0 %	
Battery pack 3 SOH	0 %	
Battery Pack 3 Battery Cycle Count	0	
Battery Pack 3 Cumulative Discharge	0 kWh	

6.2.3 Grid CODE

Under this setting, you can choose the Grid Standard that applies to your energy storage system, with the default set to the Local Standard.



Local is a customized Grid standard that specifies the widest output voltage range and output frequency range. It is applicable to most energy storage systems.




Table 6-1 lists the specifications of different Grid Standards.

Table 6-1 Grid Specifications

Grid		Output Voltage Range (VAC)	Output Frequency Range (Hz)	Start Delay (s)
1	China	187–252	49.5–50.2	30
2	Germany	184–264	47.5–51.5	60
3 Australia	AUS-A	180–265	47–52	60
	AUS-B	180–265	47–52	60
	AUS-C	180–265	45–55	60
4 Italy	CEI0-21	195–264	49.8–50.2	60
	CEI0-21 ACEA	195–264	49.8–50.2	60
5	Spain	196–253	48–50.5	180
6	U.K.	184–264	47–52	180
7	Hungary	196–253	49–51	300
8	Belgium	184–264	47.5–51.5	60
9	New Zealand	180–260	45–52	60

10	Greece	184–264	49.5–50.5	180
11	France	184–264	47.5–50.4	60
12	Bangkok	198–242	49–51	150
13	Thailand	198–242	47–52	60
14	South Africa	180–260	47.0–52	60
15	50549	184–264	47.5–51.5	60
16	Brazil	184–264	59.5–60.5	60
17	0126	184–264	47.5–51.5	60
18	Ireland	184–264	47–52	180
19	Israel	195.5–253	47.0–51.5	60
20	Poland	195.5–253	49.00–50.05	60
21 Chile	Chile-BT	176.0–242	47.5–51.5	60
	Chile-HD	198.0–242	49–51	300
	Chile-LD	198.0–242	49–51	300
22	Local	150–280	45.0–55	30
23	60Hz	184–264	59.5–60.5	60
24	Denmark	195.5–253.0	47.5–51.5	60
25	Sweden	195.5–253.0	47.5–51.5	60
26	Austria	184–264.5	47.5–51.5	300

6.2.4 Grid setting

When you select the Grid Standard in GRID CODE, these parameters are set automatically. During operation, when the inverter detects that these settings have been reached or exceeded, the inverter stops generating power.



Changing the setting of these parameters is not recommended.
After adjusting one or more parameters, please restart the system.

These are the settings:

- **POWER FACTOR:** The acceptable range is L0.8–L1.00 and C0.8–C1.00. The default setting is PF1.0.
- **REACT POWER:** The acceptable range is L00%–L60% and C00%–C60%.
- **Reactive power control:** By default, both are disabled.

GRID POWER

Active setting: The setting value is a percentage of the rated power of the system. It can be set from 0% to 100%, and the default value is **100%**.

GRID U and GRID F:

Table 6-3 BY PASS Parameters for Run Setting

Parameter	Description	Default
GRID U MAX	Maximum voltage of the Grid	270 VAC
GRID U MIN	Minimum voltage of the Grid	180 VAC
GRID F MAX	Maximum frequency of the Grid	52.5 Hz
GRID F MIN	Minimum frequency of the Grid	47 Hz
BYPASS U MAX	Maximum voltage of the Grid	270 VAC
BYPASS U MIN	Minimum voltage of the Grid	180 VAC
BYPASS F MAX	Maximum frequency of the Grid	52.5 Hz
BYPASS F MIN	Minimum frequency of the Grid	47 Hz

OVER VOLT and UNDER VOLT :

By default, **OVER VOLT** and **UNDER VOLT** are disabled. You can enable them and set the voltages.

OVER VOLT: When it is enabled, you can set **VOLT**. If the AC output voltage is higher than the set value, the output power decreases. The default value of VOLT is 270 V.

UNDER VOLT: When it is enabled, you can set **VOLT**. If the AC output voltage is lower than the set value, the output power decreases. The default value of VOLT is 200 V.

OVER FREQ and UNDER FREQ

By default, **OVER FREQ** and **UNDER FREQ** are disabled. You can enable them and set the frequencies:

OVER FREQ: When it is enabled, you can set **FREQ**. If the AC output frequency is higher than the set value, the output power decreases. The default value of FREQ is 52 Hz.

UNDER FREQ: When it is enabled, you can set **FREQ**. If the AC output frequency is lower than the set value, the output power decreases. The default value of FREQ is 48 Hz.



By default, the above four types of derating are disabled. If you need to use this function, you need to enable it manually.

QU-Response Time

QU-Response Time allows you to set the necessary time for the output reactive power to reach the Grid Standard level. The selected Grid Standard determines

the time, so DO NOT change it if the Grid is not changed. The default value is 15 seconds

Soft Start Ramp Rate

Soft Start Ramp Rate means the change of output power per minute.

The selected Grid Standard determines the rate, so **DO NOT** change it if the Grid is not changed. The value of **100%** means that the output power can reach the rated power within one minute. The range for this parameter is **0%** to **300%**, and the default value is **100%**.

GFCI CHK ENB

The RI-ENERGYFLOW-STACK supports the connection of a ground failure circuit interrupter to monitor the AC Grid connection. By default, this feature is enabled.

VRT ENABLE

VRT ENABLE is to enable or disable voltage-ride-through.

When you select the Grid Standard in **Grid Setting**, **VRT ENABLE** is set automatically.



Changing the setting of **VRT ENABLE** is not recommended.

15:53

Grid Setting
3517727893

Grid Code
Grid Setting
Scene setting

Reactive setting
0 %
>

Reactive power control
Control based on the power factor
>

Power factor setting
1.00
>

Active setting
100 %
>

Min Grid voltage
180.0 V
>

Max Grid Vlot
260.0 V
>

Min Grid Freq
45.00 Hz
>

Max Grid Freq
55.00 Hz
>

Bypass Volt-Min
180.0 V
>

Bypass Volt-Max
260.0 V
>

Bypass Freq-Min
45.00 Hz
>

Bypass Freq-Max
55.00 Hz
>

Over Volt Start Enable

Over Freq Start Enable

15:53

Grid Setting
3517727893

Grid Code
Grid Setting
Scene setting

Bypass Volt-Max
260.0 V
>

Bypass Freq-Min
45.00 Hz
>

Bypass Freq-Max
55.00 Hz
>

Over Volt Start Enable

Over Freq Start Enable

Under Volt Increase Enable

Under Freq Increase Enable

Over Volt Start
270.0 V
>

Over Freq Start
52.00 Hz
>

Under Volt Increase Point
200.0 V
>

Under Freq Increase Point
48.00 Hz
>

Soft Start Ramp Rate
-- %/min
>

QU-Response Time
15000 ms
>


GFCI Check Enable

VRT Enable

6.2.5 Scene setting

WORK MODE

The RI-ENERGYFLOW-STACK supports three working modes: **SELF CONSUME**, **PEAK SHIFT**, and **BAT PRIORITY**. For more information, see Working Modes.



SELF CONSUME: This is the default working mode. In this mode, the batteries are charged by the PV panel by default.

On the **CHARGE FROM GRID** page, you can enable the batteries to be charged by the Grid. When SELF consumption charge Enable is enabled, you can set the time (up to two each) and the maximum SOC for charging. Charging will automatically stop when the set time or MAX SOC is reached.

PEAK SHIFT: During the charging time, the batteries are forced to be charged by the Grid and/or the PV panels. During the discharging time, the batteries are forced to be discharged to the connected load. You can set times for charging and discharging (up to five each), select **CHARGE** or **DISCHR** through the **SOLARMAN** Smart App to charge or discharge the battery. During the charging time, the batteries are forced to be charged by the Grid and/or the PV panels. During the discharging time, the batteries are forced to be discharged to the connected load.

BAT PRIORITY: This mode is also known as the UPS mode, which is used in situations where a battery serves as an EPS power source. The battery only discharges when the Grid power is down, helping to extend the battery's lifespan. If the battery is not fully charged, it will continue charging, and the charging power can come from either solar power or the utility Grid. The goal is to keep the battery fully charged. During a power outage, the system operates Off-Grid to provide power to the EPS, which can be understood as the EPS function of a UPS.

ZERO EXPORT

By default, this feature is disabled. When the feature is enabled, the system outputs power to the Grid and you can set the power limit in the range from 10 W to the rated power of the system.



Max. DC input Voc should be less than 430V in zero-export application.


Peak Shaving Power Enable

After enabling the peak shift power control, you can set the peak power and valley power of the load power.




The peak power setting value must be greater than the valley power, otherwise the setting will be invalid.

The operation logic is shown in the figure:



Demand Control Enable

- ①. This function is applicable to any operating mode of the inverter when drawing power from the Grid.
- ②. This function is designed to limit the amount of power drawn by the inverter from the Grid. By enabling the "demand control" setting and setting the "demand power" to a range of 0–20,000W, when this function is enabled, the load power + charging power = demand power.



6.2.6 Advanced Function

REMOTE CTRL

By default, this feature is enabled/

Remote control to turn the inverter on and off. By default, this feature is enabled.

START DELAY

By default, when power is supplied to the inverter, there is a 30-second delay before the inverter starts.

You can increase or decrease the delay time in the range of 20–300 seconds. See GRID CODE for the start delay time for the selected Grid Standard.

GENERATOR

You can use a generator, for example, a wind generator or a diesel generator, as an EPS supply to the RI-ENERGYFLOW-STACK energy storage system.

By default, this feature is disabled. When Grid power is not available, you can manually enable generator mode and connect the load to the generator.

ISLAND

- To enable anti-islanding protection. This is for use by maintenance personnel only.

BAT WAKE-UP

The battery will go to sleep in these states:

- Over-discharge protection.
- No communication between the battery and the external system and no charging or

discharging current for a period.

By default, the system monitors the SOC and DOD of the batteries. You can set the system to wake up the batteries from sleep and to check the SOC and DOD at a set interval.

HEATING FILM




Only applicable to the batteries with heating films.

By default, the setting is AUTOMATIC. It means the film is automatically turned on or off based on the ambient temperature.

CT OR METER

The RI-ENERGYFLOW-STACK supports connecting an external CT or a smart meter for measuring the energy consumption.

By default, CT is selected. If you want to connect a smart meter, five brands are supported currently. The YADA YDS70-C16 is recommended.



PV INPUT

There are two modes for PV inputs: independent and parallel. Set the appropriate PV input mode based on the actual connection of the PV strings.

The default setting is INDEPENDENT. **If independent mode is selected when the PV strings are actually connected in Parallel, it results in an imbalanced distribution of power in the PV strings.**

DRM ENABLE

The RI-ENERGYFLOW-STACK supports DRM.

By default, this feature is disabled. In the countries where DRM is mandatory, enable the DRM feature. When the DRM connection is done, you must set **DRM ENABLE** to **ENABLE**. For more information about DRED connection, see [\(Optional\) Connecting a DRED or an RRCR](#).

AC COUPLE

If you want to connect an inverter to your PV panels to build an AC-coupling system, you must enable **AC COUPLE**.

By default, this feature is disabled. For more information, see [AC-coupling System](#).

EPS ENABLE


By default, the RI-ENERGYFLOW-STACK automatically switches to EPS power when a Grid power failure occurs.

PARALLEL

When more than one inverter is installed in parallel, you must enable **PARALLEL** and set the addresses for the inverters.

When a parallel system is installed and **PARALLEL** is enabled, assign an address (a value from 1 to 4) to each inverter. The address of the primary inverter must be set to 1. A maximum of four inverters are supported. For more information, see [Installing a Parallel System](#).

By default, this feature is disabled.



The settings: GRID setting 2, QU-Set, P(U)&P(f), Reconnect &VRT, and QP-SET are all set to default. It is not recommended for the user to modify these settings.

6.2.7 System-setting

Reboot Inverter

The command can be issued to restart the inverter.

Factory Data Reset


You can reset the inverter to the default factory settings.

Clear statistics

The command issued will clear all statistical information.


Remote Shutdown

After enabling REMOTE CTRL, sending this command will put the inverter into standby mode. After disabling this function, the inverter will return to normal operation.



6.2.8 Equipment Basic Information

- **FIRMWARE:** The version of the firmware in ARM and DSP.
- **MODEL SN:** The serial number of the hybrid inverter in use.
- **INV MODEL:** The model of the hybrid inverter in use.
- **Bat Name:** The serial number of the battery in use.
- **System Time:** setting the date, time, and day of the week for the system.



6.2.9 Electricity Generation

In this interface, you can view the voltage, current, and power of the two photovoltaic inputs, PV1 and PV2, of the inverter.

Others	Electricity Generation	Alert	1
DC Voltage PV1	422.9	V	
DC Voltage PV2	421.5	V	
DC Current PV1	8.38	A	
DC Current PV2	6.88	A	
DC Power PV1	3548	W	
DC Power PV2	2900	W	


6.2.10 Alert

The fault codes of the inverter in operation can be viewed on this interface.

Electricity Generation	Alert	Temperature	C
DSP Alarm Codes	W05 Bat Loss W06 Bat Under Volt		
DSP Error Codes	--		
ARM alarm code	--		


6.2.11 Temperature

In this interface, you can view the real-time temperature status of the four internal points of the inverter.



6.2.12 Grid Information

In this interface, you can view the inverter's Grid-side voltage, current, frequency, and power status.



6.2.13 Electricity Consumption Statistics


- **E-TODAY, E-MONTH, E-YEAR, and E-TOTAL:** The electricity generation for the day, for the current calendar month, for the current calendar year, and since system installation, including the electricity generated by the PV panels, the electricity sold to the Grid, the electricity purchased from the Grid, and the power consumption of the loads.



17:43		****  
< Electricity Consumption... 3517727893		↻
nation	Electricity Consumption Statistics	Inverte
Energy- from grid/today	37.7 kWh	
Energy- from grid/this month	0 kWh	
Energy- from grid/this year	0 kWh	
Total Energy Buy	38.2 kWh	
Energy- to grid/today	64.0 kWh	
Energy- to grid/this month	0 kWh	
Energy- to grid/this year	0 kWh	
Total Energy Sell	76.0 kWh	
Energy consumed today	264.6 kWh	
Energy consumed this month	0 kWh	
Energy consumed this year	0 kWh	
Cumulative energy consumed	302.7 kWh	
Energy generated today	323.2 kWh	
Energy generated this month	0 kWh	

6.2.14 EPS Information

The inverter's load-side voltage, current, frequency, and power status can be viewed on this interface.




6.2.15 Other Information

- **CONNE. TIMES:** Number of inverter connections to the Grid.
- **PV Input Mode:** Display PV input mode, independent or parallel mode.
- **Remote Shutdown Status:** Normal or off state
- City electricity standard: The Grid Standards set by the inverter.
- Speed of the fan: Display fan speed
- System Application Scenarios: The system application scenarios of inverters.
- System Status: System status
- Inverter Status: Inverter Status.
- DC-DC Status: The working status of the battery side.
- BUS Voltage: The real-time value of the busbar voltage.
- DC-BUS Voltage: The real-time value of the DC bus voltage.

15:57		 16
<		Others Information 3517727893
		↻
ip Information	Others Information	Bat Information
Time/Connected to grid		16
PV Input Mode		Parallel
Remote Shutdown Status		Normal
City electricity standard		Local
speed of the fan		4350 rpm
System Application Scenario		Peak Clipping And Valley Filling
System Status		Hybrid Grid Connection
Inverter status		Grid connected
Dcdc Status		Standby
BUS Voltage		420.6 V
Dcbus Voltage		420.6 V

6.2.16 POWER FLOW




Click to enter the "POWERFLOW" interface for a more intuitive understanding of the inverter's current operating status.




6.2.17 Device Self-Test

In Italy, when an RI-ENERGYFLOW-STACK energy storage system is installed, it must pass the Device Self-Test in the specified operate mode before being connected to the local Grid. The specific operation steps are as follows:

- ①. Click on device self-test in the application interface.
- ②. Click the "Add Device" button to enter the "Select Device" page.
- ③. Enter the SN number of the device (Only displays equipment that has been added to the power station) .
- ④. After selecting the device, click on start self-test.
- ⑤. Equipment self-test requires waiting for 10 minutes.
- ⑥. After the self-inspection is completed, click on the self-inspection record to enter the details.





210213220D95579100001 2025-06-11 17:11:19		
59.S1 PASS		
	Limit	Trip
Value	253V	230.3V
Time	3000ms	3000ms
59.S2 PASS		
	Limit	Trip
Value	264V	230.2V
Time	100ms	100ms
27.S1 PASS		
	Limit	Trip
Value	195V	230.7V
Time	100ms	100ms
27.S2 PASS		
	Limit	Trip
Value	184V	230.4V
Time	100ms	100ms
81>.S1 PASS		
	Limit	Trip
Value	50.2Hz	49.99Hz
Time	100ms	100ms
81>.S2 PASS		
	Limit	Trip
Value	51.97Hz	49.98Hz
Time	100ms	100ms

6.3 Operating Battery Packs

6.3.1 Indicator Lights and State


A battery pack can be in five states: **OFF**, **NORMAL**, **ALARM**, **PROTECTION**, and **FAULT**. In each state, the battery pack can operate in different modes.

There is an indicator light whose color is variable on the power button.

Product status	LED indicator status			
	LED color	LED blink status		
		Blink Mode	Blinking (Sec)	Off (Sec)
OFF	OFF	OFF all the time		
Normal	Green	ON all the time		
Alarm	Red	Blinks once every 1.5 seconds	0.75	0.75
Protection	Red	Blinks once every 0.5 seconds	0.25	0.25
Fault	Red	ON all the time		

6.3.2 Turning on a Battery Pack

Press the power button (1~3s) until the indicator light of the power button are on.



6.3.3 Turning off a Battery Pack

Press the power buttons (1~3s) until the indicator light of the power button goes out.



Precaution:

Please make sure that the battery is not being charged or discharged before performing a shutdown.

7 Residential ESS Third-party EMS Technical Specification

7.1 Functional Description

The inverter provides two RS485 (Modbus RTU) interfaces for monitoring and control. When connecting a third-party EMS for remote power management, the COM / WLAN/4G / LAN port should be linked to the data logger, while the DRY/METER port connects to the third-party controller.

 NOTE	When integrating with a third-party monitoring platform, the Data Logger must remain connected.
--	---

7.2 Applicable Models

7.2.1 Device Compatibility

Device Type	Modbus TCP (Ethernet)	RS485	Firmware Version Requirements*
E(3.68/5/6)KS-D22	No	Yes	ARM version 1.3.00 or higher

*Note: Contact the technical team if the inverter firmware version is unsupported.

7.2.2 Modbus Protocol Version

The current Modbus standard protocol:

Hybrid Inverter MODBUS RS485 Communication Protocol V3.1.2

Based on the above version, we have streamlined a version of the protocol which includes commonly used registers for third-party EMS providers (recommend using):

Residential ESS Modbus Protocol—Lite_V1.0.0

7.3 Configuration Methods

 NOTE	When using the meter port for communication, please connect the smart meter to the third-party EMS controller instead.
--	--

7.3.1 Single-Phase Connection




Figure 1 Single-phase connection diagram

- Connect the third-party EMS controller to the CT/METER Port using an RS-485 cable.
- Attach RS485-A to PIN6 and RS485-B to PIN5, as shown below:

PIN ID	RS485 Signal
5	RS485-B
6	RS485-A

- Connect the Wi-Fi / LAN Logger to the COM port.

7.4 Inverter Settings


When connecting the third-party EMS controller via the Meter port, configure the following settings:

7.4.1 Set the work mode to Self-consumption and Disable Charge from Grid

VPP function requires Self-Consumption mode and Charge from Grid Disabled for reliable operation. These settings can be configured either directly via the APP/WEB or by writing to the corresponding Modbus registers.

7.4.1.1 Method 1: On the APP

Navigate through the Solarman APP as below:



7.4.2.2 Method 2: Setting the registers

- Set the work mode to Self-consumption

Register	Data Type	Length	Unit	Parameter
3270	16-bit Unsigned	2	-	Remote Control Enable
0: Self-Consumption (CSM) 1: Peak Shaving (PEAK SFT) 2: Battery Priority (BAT PRIO)				
Note: Must be set to 0 for remote control function to work.				

- Disable the Self-Consumption Charge-from-Grid

Register	Data Type	Length	Unit	Parameter
3314	16-bit Unsigned	2	-	Self-Consumption Charge from Grid Enable
0: Disable (default) 1: Enable				
Note: Keep set to 0 (default) to avoid overriding remote control (3270).				

7.4.2 Disable Conflicting Modes

Several additional settings must be considered. If these settings are enabled, they may override VPP Mode due to higher priority, which can cause power dispatch commands in VPP Mode to fail. Therefore, the following settings must be disabled:

- Charge from Grid in Self-Consumption Mode (see 4.1.2)
- Force Charge/Discharge
- Generator Mode

Disable the Force Charge/Discharge

Register	Data Type	Length	Unit	Parameter
3086	16-bit Unsigned	2	-	Force Charge/Discharge Enable
0: Invalid 1: Force Charge 2: Force Discharge Note: Must be set to 0 (default) to avoid overriding 3270.				

Disable Generator Mode

Register	Data Type	Length	Unit	Parameter
3086	16-bit Unsigned	2	-	Force Charge/Discharge Enable
0: Invalid 1: Force Charge 2: Force Discharge Note: Must be set to 0 (default) to avoid overriding 3270.				

7.4.3 VPP Power Control Settings

7.4.3.1 Enable VPP Control via RS48

Address: 3270

Value: 1 (Enable), 0 (Disable)

Default: 0 (Disable)

Action: Write "1" to address 3270 to enable VPP control.

7.4.3.2 Set Inverter Power via RS485

Address: 3267

Default Value: 0

Setting Range: 0 to $\pm$ Rated Power

Examples:

Writing 3000W to address 3267 sets the inverter to output 3000W to the Grid.

Writing -3000W to address 3267 sets the inverter to charge the battery at 3000W.

7.4.3.3 Disable VPP Control

Address: 3270

Value: 1 (Enable), 0 (Disable)

Action: Write "0" to address 3270 to disable VPP and revert to the mode set via the APP (Self-Consumption, Peak Shaving, ToU, or Battery Priority).

Notes:

1. If address 3270 is set to "Disable" (0) and a non-zero value is written to address 3267, address 3270 will automatically switch to "1", enabling VPP remote control.

8 Maintenance

Both users and certified professional personnel must maintain the E3.68KS-D22/E5KS-D22 energy storage system to ensure the healthy and safe operation of the system.

In this section, you can find the following:

- The inspection checklist for users of the energy storage system.
- The inspection checklist for professional personnel.
- Error codes, alarm codes, and the possible solutions of the system and the BMS.

8.1 Inspection Checklist for Users

Inspection Activity	Interval
Check for visible damage to any part of the system.	Six months
Check the inverter and battery packs for signs of wear and tear, heat damage, discoloration, and unusual smells.	Six months
Check the warning signs and guidance signs on the inverter and the battery pack for signs of wear and damage, and make sure none have been removed or obscured.	Six months
Check whether any part of the system makes an abnormal noise when the system is running.	Six months
Monitor the temperature of the battery pack and clean the battery pack if necessary.	Six months to a year
Make sure that the ground around the system is clean and tidy.	Six months to a year
Check the maintenance access to make sure that it is clear and unobstructed.	Six months to a year
When the system is running, check the voltage, temperature, and other parameters of the battery packs.	Six months
When the system is running, check the parameters of the inverters.	Six months
Check the battery packs for ineffectiveness or damage.	Six months

8.2 Inspection Checklist for Professional Personnel

WARNING

- The equipment must be opened only by professional personnel that have been certified by Rayleigh Instruments.
- During inspection and maintenance, wear protective personal equipment, including insulated gloves, protective shoes, and anti-noise earplugs.
- Follow local and international safety standards, regulations, and specifications to do the maintenance.
- Contact Rayleigh Instruments promptly if you encounter anything not covered in this manual.

CAUTION

Before maintenance, disconnect all the electrical connections. Wait at least five minutes after disconnection, so that the residual voltage of the capacitors falls to a safe voltage. Use a multi-meter to make sure that the equipment is completely discharged.

Inspection Activities	Interval
Check electrical connections for looseness.	Six months to a year
Check cables for deterioration or damage.	Six months to a year
Check cable terminal screws for looseness.	Six months to a year
Check cable terminals for signs of overheating.	Six months to a year
Check the ground connection.	Six months to a year
Check whether cable ties are still attached to the cable.	Six months to a year
Check the EMS, SOLARMAN app, and other related equipment for failure or damage.	Six months to a year

8.3 Troubleshooting

When you see the red alarm light on the inverter, you can find possible solutions in this section. If the problem persists after trying these solutions, please contact Rayleigh Instruments or an authorised distributor.

When a problem is successfully solved, after a period of time, the red LED alarm light turns off, but you can always view the error saved in the error records. For more information, see Viewing INQUIRE.

8.3.1 Error Codes of the System

Code	Description	Possible Solutions
F00	Soft Time Out: Soft-start timeout.	Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
F01	INV Volt Short: The inverter output is shorted.	1. Disconnect all power sources and shut down the inverters and the battery packs. 2. Disconnect the load. 3. Power on and restart all the inverters and the battery packs. 4. If no error is reported, it means the load is shorted. Check the load. If the code is still shown, contact Customer Service.
F02	GFCI Sensor Fault: A failure occurs to the Ground Fault Circuit Interrupter (GFCI) sensor.	1. Disconnect all power sources. 2. Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
F04	Bus Volt Low: The bus voltage is low.	1. Check the settings of the input mode. 2. Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
F05	Bus Volt High: The bus voltage is high.	
F06	Bus Short Circuit: The bus is shorted.	Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
F07	PV ISO Under Fault: The insulation resistance of a PV panel is low.	1. Check the ground connection. 2. Check the ground resistance of PV+ and PV-: ▪ If the resistance is smaller than 2 MΩ, check the PV string for ground fault or poor ground insulation. If necessary, contact Customer Service. ▪ If the resistance is greater than 2 MΩ and the error code is still shown, contact Customer Service.

Code	Description	Possible Solutions
F08	PV Input Short Circuit: The PV input is shorted.	1. Check the settings of the input mode. 2. Disconnect the PV input. 3. Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
F09	Bypass Relay Fault: A failure occurred to the bypass relay.	1. Disconnect the PV input. 2. Restart the inverter and wait until it runs correctly.
F19	EPS Relay Fault: A failure occurred to the EPS relay.	If the code is still shown, contact Customer Service.
F10	INV Curr Over: The output current on the inverter exceeds the threshold.	1. Wait five minutes for the inverter to restart automatically. 2. Check the EPS loads. If the load exceeds the rated output power of the inverter, disconnect some load. If the code is still shown, contact Customer Service.
F11	INV DC Over: The DC component of the output current of the inverter is too high.	Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
F12	Ambient Over Temp: The ambient temperature is too high.	1. Restart the inverter. 2. Let the inverter cool for a few minutes and then restart it.
F13	Sink Over Temp: The temperature of the heat sink is too high.	3. Observe whether the inverter can run correctly. 4. Make sure that the ambient temperature is in the range of -25°C to 60°C. If the code is still shown, contact Customer Service.
F15	DisChg Curr Over: The battery is discharged with over current.	1. Wait five minutes for the inverter to restart automatically. 2. Check the EPS loads. If the load exceeds the rated output power of the inverter, disconnect some load. If the code is still shown, contact Customer Service.

Code	Description	Possible Solutions
F16	Chg Curr Over: The battery is charging with over current.	Check the battery wiring port for short circuits. Restart the inverter and the battery packs. If the code is still shown, contact Customer Service.
F17	Current Sensor Fault: A failure occurred to the current sensor.	Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
F18	INV Abnormal: Abnormal output voltage or output frequency of the inverter.	Contact Customer Service.
F20	Always Over Load: The EPS load always exceeds the rated output power of the system.	Check the EPS loads. If the load is lower than the rated output power of the inverter and the error is still shown, contact Customer Service.
F22	Parallel Communicate Fault: A failure occurred to the communication between the inverters in a parallel system.	1. Check the parallel cable for connection. 2. Check the inverter address settings. In a parallel system, the address of the primary inverter must be set to 1, and the addresses of the other inverters must be set to 2, 3, or 4. If the code is still shown, contact Customer Service.
F23	Parallel Grid Abnormal: In a parallel system, some connections are incorrect.	1. Check the wiring at the Grid end and make sure the wiring is correct. 2. Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
F24	EPS Air Switch Abnormal: An error occurred to activation of the air switch on the EPS load end.	1. Turn off all the switches on the EPS load end. 2. If the code is still shown, contact Customer Service.
F25	Parallel Power Imbalance: Power imbalance occurs to the parallel system.	1. Turn off all the switches on the EPS load end. 2. Restart the inverter and wait until it runs correctly.

Code	Description	Possible Solutions
F26	Parallel Inverter Grid Phase Sequence Abnormal	1. Make sure that the phase sequence at the Grid end of the inverter is consistent. 2. If the code is still shown, contact Customer Service.
F32	DSP ARM SCI Fault: A failure occurs to the communication between DSP and ARM.	Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.

8.3.2 Alarm Codes of the System

Code	Description	Possible Solutions
W00	Grid Volt Low	Check the local voltage and frequency for their compliance with the inverter specifications: • If the voltage and frequency are within the acceptable range, wait two minutes for the inverter to run correctly. If recovery is not possible or the fault repeats, contact Customer Service. • If the voltage and frequency are beyond the range or are unstable, contact the local power company.
W01	Grid Volt High	
W02	Grid Frequency Low	
W03	Grid Frequency High	
W04	Solar Loss: No PV solar panels are connected to the system, or the input voltage from the PV solar panels is too low.	1. Check the PV connection. 2. Check the PV availability. If the connections are correct and the alarm code is still shown, contact Customer Service.
W05	Bat Loss: No battery packs are connected to the system, or the battery voltage is too low.	1. Check the battery connection. 2. Check the battery wiring port for short circuits. If the connections are correct and the alarm code is still shown, contact Customer Service.
W06	Bat Under Volt: Under voltage has occurred in the battery.	Check the battery packs for their availability. If the battery voltage is lower than the lowest battery terminal input voltage acceptable to the inverter, charge the battery until it reaches the acceptable battery input voltage of the inverter. If the code is still shown, contact Customer Service.
W07	Bat Volt Low: The battery voltage is too low.	

Code	Description	Possible Solutions
W08	Bat Volt High: The battery voltage is higher than 57.5 V and the battery has shut down because of the high voltage.	1. Check the battery for its compliance with its pre-settings. 2. If the battery complies with the pre-setting, restart it. If the code is still shown, contact Customer Service.
W09	Over Load: An overload has occurred because the connected load exceeds the rated power of the inverter.	1. Wait five minutes for the inverter to restart. 2. If the EPS loads are higher than the rated output power of the inverter, disconnect some load.
W10	GFCI Over: High current leakage has occurred.	1. Check the PV string for direct or indirect grounding. If such grounding is discovered, correct it. 2. Check the peripherals of the inverter for current leakage. If current leakage is discovered, address it. If the code is still shown, contact Customer Service.
W12	Fan Fault: The fan has malfunctioned.	Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
W13	BAT Power Down: The battery has shut down because the SOC is low.	Check the SOC. Make sure that the SOC is not lower than the difference between 100% and the set DOD. If it is lower than the difference, charge the battery.
W14 W15 W16 W17 W18 W21 W22	BMS alarms.	For more information, see BMS ALARM Warnings.
W19	BMS Volt Imbalance: A voltage imbalance has occurred to the battery of the BMS.	Contact Customer Service.
W20	BMS Communicate Fault: The communication between the BMS and the inverter has failed.	Make sure that the COM cable between the inverter and the battery pack is in good condition and is connected correctly.
W23 W24	BMS protection warning.	For more information, see BMS PROTECTION Warnings.

Code	Description	Possible Solutions
W25	BMS Updating: The BMS is updating.	You can ignore this alarm. No action is required.
W26	BMS Program Version Err: The version of the BMS program is incorrect.	Contact Customer Service.
W27	BMS Program Update Fail: The BMS program has failed to update.	Check the network and try to update the program again.
W29	Grid Volt Lock Fail: The inverter has failed to synchronize with the Grid.	Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
W30	PV Off: The PV string has requested a shutdown.	Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.
W31	System Reset: The system is reset.	Restart the inverter and wait until it runs correctly. If the code is still shown, contact Customer Service.

8.3.3 BMS Error codes and troubleshooting

Code	Description	Possible Solutions
BIT0	Battery cell overvoltage alarm	The warning unit overcharging voltage is 3650mV, where the inverter should stop charging and the BMS should not turn off the charging MOS.
BIT1	Battery cell under-voltage alarm	The warning unit over discharging voltage is 2800mV, where the inverter should stop discharging and the BMS should not turn off the discharging MOS.
BIT2	Battery PACK overvoltage alarm	The warning overall overcharging voltage is 57.6V, where the inverter should stop charging and the BMS should not turn off the charging MOS.
BIT3	Battery PACK under-voltage alarm	The warning overall over discharging voltage is 44.8V, where the inverter should stop discharging and the BMS should not turn off the discharging MOS.
BIT4	Charging overcurrent alarm	The warning charging overcurrent is 100A, where the inverter should stop charging and the BMS should not turn off the charging MOS.
BIT5	Discharging the overcurrent alarm	The warning current of discharging overcurrent 1 is 100A where the inverter should stop discharging and the BMS

		should not turn off the discharging MOS. This alarm will automatically stop after 1min or when the charging current is greater than 1A.
BIT8	Charging high temperature alarm (cell temperature)	The protective limit of charging high temperature is 57°C where the BMS should forcibly turn off the charging MOS.
BIT9	Discharging high temperature alarm (cell temperature)	The warning discharging high temperature is 55°C, where the inverter should stop discharging and the BMS should not turn off the discharging MOS.
BIT10	Charging low temperature alarm (cell temperature)	The warning charging low temperature is 2°C, where the inverter should stop charging and the BMS should not turn off the charging MOS.
BIT11	Discharging low temperature alarm (cell temperature)	The warning discharging low temperature is -18°C, where the inverter should stop discharging and the BMS should not turn off the discharging MOS.
BIT12	High ambient temperature alarm	The warning high ambient temperature is 65°C, where the inverter should stop charging and discharging and the BMS should forcibly turn off the charging and discharging MOS.
BIT13	Low ambient temperature alarm	The warning low ambient temperature is -15°C, where the inverter should stop charging and the BMS should forcibly turn off the charging MOS.
BIT14	MOSFET high temperature alarm	The warning MOS over-temperature is 90 °C, where the inverter should stop charging and discharging and the BMS should not turn off the charging and discharging MOS.
BIT15	Low SOC alarm	The warning low battery SOC is less than 5%, where the inverter should stop discharging and the BMS should not turn off the charging and discharging MOS and should not alarm during charging.

8.3.4 BMS Protection codes and description

Code	Description	Possible Solutions
BIT0	Battery cell overvoltage protection	The unit overcharging protection voltage is 3700mV, where the inverter should stop charging and the BMS should forcibly turn off the charging MOS.
BIT1	Battery cell under-voltage protection	The unit over discharge protection voltage is 2500mV, where the inverter should stop discharging and the BMS should forcibly turn off the discharging MOS. After 30 seconds of over discharge protection, if the battery still cannot be restored, it will enter a low power consumption mode.
BIT2	Battery PACK overvoltage protection	The overall overcharge protection voltage is 59V, where the inverter should stop charging and the BMS should turn off the charging MOS.
BIT3	Battery PACK under-voltage protection	The overall over discharge protection voltage is 40V, where the inverter should stop discharging and the BMS should forcibly turn off the discharging MOS. After 30 seconds of over discharge protection, if the battery still cannot be restored, it will enter a low power consumption mode.
BIT4	Charging overcurrent protection	The protective limit of charging overcurrent is 120A, where the BMS should forcibly turn off the charging MOS. This state will be locked and not be exited automatically if it occurs continuously for 10 times.
BIT5	Discharging overcurrent protection	The protective limit of discharging overcurrent 1 is 130A and the protective limit of discharging overcurrent 2 is 200A with a delay of 100ms, where the BMS should forcibly turn off the discharging MOS. This state will be locked and not be exited automatically if it occurs continuously for 10 times.
BIT6	Short circuit current protection	The short circuit protection current is no less than 350A with a delay of 300us, where the BMS should forcibly turn off the discharging MOS.
BIT7	Charging overvoltage protection	The overall overcharge protection voltage is 59V, where the inverter should stop charging and the BMS should turn off the charging MOS.

BIT8	Charging high temperature protection (cell temperature)	The protective limit of charging high temperature is 57°C, where the BMS should forcibly turn off the charging MOS.
BIT9	Discharging high temperature protection (cell temperature)	The protective limit of discharging high temperature is 57°C, where the BMS should forcibly turn off the discharging MOS.
BIT10	Charging low temperature protection (cell temperature)	The protective limit of charging low temperature is 0°C, where the BMS should forcibly turn off the charging MOS.
BIT11	Discharging low temperature protection (cell temperature)	The protective limit of discharging low temperature is -20°C, where the BMS should forcibly turn off the discharging MOS.
BIT12	MOSFET high temperature protection	The protective limit of MOS over-temperature is 110°C, where the BMS should forcibly turn off the charging and discharging MOS.
BIT13	High ambient temperature protection	The protective limit of high ambient temperature is 70°C, where the BMS should forcibly turn off the charging and discharging MOS.
BIT14	Low ambient temperature protection	The protective limit of low ambient temperature is -25°C, where the BMS should forcibly turn off the charging and discharging MOS.
BIT15	Heating function fault	Reset the battery PACK; If the fault is not clear, contact the service engineer.

8.3.5 BMS Fault codes and description

Code	Description	Possible Solutions
BIT0	Charging MOSFET malfunction	Restart the battery PACK, if the fault still exists, contact the manufacturer and lock it until the technical personnel resolve the problem.
BIT1	Discharging MOSFET malfunction	Restart the battery PACK, if the fault still exists, contact the manufacturer and lock it until the technical personnel resolve the problem.
BIT2	Temperature sensor malfunction	Restart the battery PACK, if the fault still exists, contact the manufacturer and lock it until the technical personnel resolve the problem.
BIT3	Cell voltage sampling	Reset the battery PACK; If the fault is

	fault	not clear, contact the service engineer.
BIT4	Battery cell malfunction	Restart the battery PACK, if the fault still exists, contact the manufacturer and lock it until the technical personnel resolve the problem.
BIT5	Front-end sampling communication failure	Restart the battery PACK, if the fault still exists, contact the manufacturer and lock it until the technical personnel resolve the problem.
BIT6	Heating control MOSFET fault	Reset the battery PACK; If the fault is not clear, contact the service engineer.
BIT14	Reverse DC connection	Check whether or not the wiring between the battery PACK and the positive and negative wires of the inverter battery is proper.

9 Storing and Recharging Batteries

9.1 Storage Environment Requirements

It is recommended that you begin using the battery soon after delivery rather than store the battery pack for a long time. The maximum storage life of a battery pack is three years.

The intended storage environment of the battery pack should meet these requirements:

- Ambient temperature: 0°C to 35°C.
- Recommended storage temperature: 20°C to 30°C.
- Relative humidity: 0–95% (No condensation).
- Dry, ventilated, and clean area.
- No contact with corrosive organic solvents, gases, and other substances.
- No direct sunlight.
- More than two meters from any heat source.



WARNING

When storing a battery in its packaging, make sure that the packaging box is intact and that the battery is appropriately placed and stacked, and the above mentioned requirements are met.

9.2 Interval for Recharging Batteries

While in storage, batteries must be recharged at specified intervals.

Table 9-1 Recharge Batteries at Specified Intervals during Storage

Actual Storage Temperature	Interval
$-10^{\circ}\text{C} \leq T \leq 30^{\circ}\text{C}$	12 months
$30^{\circ}\text{C} < T \leq 45^{\circ}\text{C}$	8 months

For example, whether the battery is recharged every 8 months or every 12 months, it can only be recharged a maximum of three times within three years. If the battery has not been recharged within three years, it is recommended that the battery pack be discarded.

Lithium-ion batteries lose capacity during storage. After 12 months of storage at the intended storage temperature, the capacity generally falls irreversibly by 3–10%. Batteries with less than 100% capacity after storage cannot pass the discharge testing and acceptance testing.

9.3 Recharging a Battery

If a battery has not been charged for two weeks or more after a deep discharge, or the SOC of a battery is less than 50% after a long period of storage, the battery must be charged to 50%.

WARNING

Before charging the battery, check it for deformation, case damage, or leakage, and if you find any of these things, do not charge the battery.



If the SOC of a battery pack is not less than 50% after more than 12 months of storage, it is not necessary to recharge the battery.

NOTES

Prepare a cross screwdriver and insulated rubber gloves.

CAUTION

When you connect the power wires, wear insulated rubber gloves.

PROCEDURE

Step 1. Connect power cables to the battery charger correctly. The maximum number of battery pack connected parallel is 4.

Step 2. Press the battery “start key” for 1~3 seconds to start the battery pack. Check the LED on the battery “start key” is on.

Step 3. Turn on the battery charger.

Step 4. Set charging parameter on the battery charger.

Case #1, One battery pack is charged. Set the charge limited voltage 57.6V; Set the charge limited current 50A;

Case #2, Two ~ Four battery packs are charged. Set the charge limited voltage 57.6V; Set the charge limited current 100A;

Step 5. After the battery is charged, switch off the battery charger and press the battery “start key” for 1~3 seconds to switch off the battery pack.

10 Limited Warranty

If the equipment fails during the warranty period, Rayleigh Instruments and its authorised partners will provide free service or replace the unit or part with a new one.

10.1 What This Warranty Covers

During the warranty service, the professional personnel certified by Rayleigh Instruments or its authorised partners will determine the problem based on the current status of the equipment, confirm the time required for repair or replacement, and complete the repair or replacement within the agreed time.

If a unit or part is replaced, the replaced unit or parts will be recycled and disposed of by Rayleigh Instruments or its authorised partners.

The replacement unit or parts provided by Rayleigh Instruments are determined by the inventory and may not be brand new, but will be in good working condition and at least functionally equivalent of a brand new unit or part. The replacement unit or part will be warranted for the remainder of the original warranty period of the equipment.

10.2 How to Obtain Warranty Service

If the equipment does not function as warranted during the warranty period, you can contact Rayleigh Instruments or its authorised partners to obtain warranty service.

10.3 Customer Responsibility for Warranty Service

To obtain warranty service, you must take these steps:

- Step 1.** Provide the purchase invoice to prove that the whole unit or parts are still under warranty.
- Step 2.** Make sure that the nameplate on the equipment is intact and legible.
- Step 3.** Make sure that the installation, modification, replacement, or removal of the whole unit or part of the equipment has been done by professional personnel certified by Rayleigh Instruments or its authorised partners.

Step 4. Make sure that the equipment has been operated in the intended environment described in this manual or other documents provided by Rayleigh Instruments.

Step 5. Make sure that no non-standard parts or parts not supplied by Rayleigh Instruments are used in the equipment.

Failure to comply with any of the above information, Rayleigh Instruments or its authorised partners have the right to refuse to provide warranty service.

10.4 Limitation of Liability

Rayleigh Instruments has the right to refuse to honor the quality warranty for any of the following reasons:

- Damage during transportation, including paint scratches caused by friction inside the package during transportation, and damage sustained while being transported by you or a third party commissioned by you.
- Operation of the equipment in an environment other than the intended environment described in this manual or other documents provided by Rayleigh Instruments.
- Failure or damage caused by installation, repair, modification, or disassembly carried out by anyone other than professional personnel certified by Rayleigh Instruments or its authorised partners.
- Failure or damage caused by the use of non-standard components or other components not provided by Rayleigh Instruments.

Rayleigh Instruments may charge a fee for repair service if you request repair of the equipment in any of the following circumstances:

- Installation and use beyond the scope of the relevant standards.
- Damage caused by unexpected natural factors.

11 Emergency Procedure

An emergency is a situation involving a major incident or the possibility of a major incident that cannot be handled according to normal procedures and requires immediate action to limit or address the consequences.

This section describes emergencies that may be encountered when you are using the RI-ENERGYFLOW-STACK energy storage system and how to handle such emergencies.

11.1 General Handling

If an emergency occurs, remember the following:

- The Grid main switch that supplies power directly to the System must be turned off.
- All load switches in the System must be turned off.
- The battery switch must be turned off.
- If you want to open the inverter or the battery pack after the power is turned off, to prevent possible fatal personal injury, use a properly calibrated voltage meter to measure the voltage at the input terminals, wait approximately 15 minutes until the DC link capacitors inside the battery pack is completely discharged, and then open the top cover to repair



WARNING

Before operating the equipment, make sure that the System is not supplied with Grid power.

11.2 Potential Emergencies

11.2.1 Battery Leakage

If the battery pack leaks electrolyte, avoid contact with the leaking liquid or gas. If you make contact with the leaking substance, take the measures listed in [Table 11-1](#) immediately.

Table 11-1 Measures to Solve Battery Leakage Emergency

Exposure	Measures
Inhalation	Evacuate contaminated area and then seek medical attention.
Eye Contact	Flush eyes with running water for five minutes and then seek medical attention.
Skin Contact	Wash affected area thoroughly with soap and water and then seek medical attention.
Ingestion	Induce vomiting and then seek medical attention.

11.2.2 Fire or Explosion

If a fire occurs in the area where the battery pack is installed, take the following measures.

WARNING

Batteries can explode when heated above 150°C. Toxic gases can leak when a battery pack burns. DO NOT approach. However, because the batteries contain only a small amount of oxygen and all batteries are equipped with explosion-proof valves, battery explosions are unlikely to occur.

Table 11-2 Handling with Fire

Handling with Fire	Description
Fire Extinguishing Agent	A respirator is not usually required. If the fire is caused by a battery, use a specialized fire extinguisher such as Noves 1230, FM-200, or a dioxin extinguisher. If the fire is not caused by a battery, use a regular ABC extinguisher.
Extinguishing Instructions	If a fire occurs while charging a battery, turn off the battery pack circuit breaker and turn off the charging power if it is safe to do so. If the battery pack is not on fire, the fire should be extinguished before the battery pack catches fire. If the battery pack is on fire, do not attempt to extinguish the fire. Instead, evacuate personnel immediately.
Methods of Handling Accidents	If the battery is in a dry environment, put the damaged battery in an isolated area and call the local fire department or service engineer. If the battery is in a wet environment, DO NOT touch anything if any part of the battery, such as the inverter or cables, is submerged. DO NOT use the submerged battery. Contact a service engineer.

11.3 Emergency Handling Plan


If an emergency occurs, follow this emergency handling plan:

- Step 1.** Turn off the AC circuit breakers.
- Step 2.** Check the control power supply. If there is no problem, supply power to the inverter again to find the cause.
- Step 3.** Record the details related to the fault so that Rayleigh Instruments can analyse and rectify the fault. DO NOT operate the equipment before the fault is rectified. Please contact Rayleigh Instruments as soon as possible.

12 Disposal

When the system reaches the end of its service life, follow these steps to dispose of the equipment:

- Step 1.** Uninstall the system:
 - 1.1 Disconnect all power sources.
 - 1.2 Disassemble all parts of the system from top to bottom.
- Step 2.** Dispose of all the parts. DO NOT dispose of the battery packs as regular household waste.



This symbol means that the labeled equipment must not be disposed of as regular household waste. It must be disposed of at an electrical and electronic equipment-recycling center.

NOTICE

If you need to replace a battery pack, you should request a new dangerous goods package, pack the battery pack, and then have the supplier pick it up.

Rayleigh Instruments does not recycle batteries. Please contact your local recycling organization for disposal. If there is no local recycling organization, you should contact the nearest recycling organization in your country.

13 Specifications

13.1 Hybrid Inverter

Dimension (W × H × D, mm)	725 × 390 × 245
Net Weight (kg)	25 (31kg with base)
Operating Temperature	-25°C to +60°C, Derated over 45°C
Operating Relative Humidity	0–95% (No condensation)
Operating Altitude	≤ 4000 m
Protective Class	Class I
Overvoltage Category	II (DC side), III (AC side)
Topology	High Frequency Isolation
Cooling	Natural Convection
Display	LED/APP
Communication Interface	RS485, CAN2.0, Wi-Fi, and 4G
Ingress Protection	IP66
Max. Conversion Efficiency (From Battery)	94.8%
Max. Conversion Efficiency (From PV)	97.2 %
Euro Efficiency	95.9% (3.68K) /96.4% (5K) /96.5% (6K)
MPPT Efficiency	99 %
Protection Function	• Short Circuit Protection • AC Leakage Fault Protection • Grounding Fault Protection • Anti-islanding Protection • Overload Protection • Surge Protection
Grid Regulation	• EN50549-10 • VDE-AR-N4105 • VDE0126-1-1 More Grid regulation certifications are to be made available. Please contact Rayleigh Instruments for the latest information.
Safety Regulation	• IEC/EN 62109-1&2 • IEC62040-1 • IEC62619

EMC	• EN61000-6-1 • EN61000-6-2 • EN61000-6-3 • EN61000-6-4 • EN61000-3-2 • EN61000-3-3 • EN61000-3-11 • EN61000-3-12
------------	--

13.2 Battery Terminal Input /Output

	3.68kW	5.00kW	6.00kW
Battery Type	Lithium or lead-acid batteries		
Voltage Range	42–58 VDC		
Rated Voltage	48 VDC		
Maximum Charge/Discharge Current	80 ADC/80 ADC	120 ADC/120 ADC	125 ADC/125 ADC
Maximum Charge/Discharge Power	3600 W/3900 W	5,000 W/5,400 W	6,000 W/6,400 W

13.3 PV Input

	3.68kW	5.00kW	6.00kW
Vmax. PV	500 VDC		
Rated Voltage	360 VDC		
PV Start Voltage	120 VDC		
MPPT Voltage Range	120–480 VDC		
MPPT Range (Full Load)	200–425 VDC	250–425 VDC	250–425 VDC
MPPT Tracker/Strings	2		
Max. Continuous PV Input Current	20 ADC × 2		
Isc PV	25 ADC × 2		
Max. Backfeed Current	0 ADC		
Max. Continuous PV Input Power	7,200 W	10,000 W	10,000 W

13.4 Grid Terminal Input / Output

	3.68kW	5.00kW	6.00kW
Rated Voltage	220/230/240 VAC		
Rated Frequency	50 Hz /60 Hz		
Maximum Continuous Input Current	32 AAC	40 AAC	40 AAC
Maximum Continuous Input Power	7,360 W	9,200 W	9,200 W
Rated Output Current	16 AAC	21.7 AAC	26.1 AAC
Maximum Continuous Output Current	16.7 AAC	22.7 AAC	27.3 AAC
Power factor (Cos phi), Adjustable	0.8 leading–0.8 lagging		
Rated Output Power	3,680 W	5,000 W	6,000 W
Maximum Continuous Output Apparent Power	3,680 VA	5,000 VA	6,000 VA
Grid Port Overcurrent Protection	40 A	63 A	63 A

13.5 EPS Load Terminal Output

	3.68kW	5.00kW	6.00kW
Rated Voltage	230 VAC		
Rated frequency	50 Hz/60 Hz		
Rated Output Current	16 AAC	21.7 AAC	26.1 AAC
Maximum Continuous Output Current	16 AAC	21.7 AAC	26.1 AAC
Rated Continuous Output Power	3,680 W	5,000 W	6,000 W
Maximum Output Apparent Power	3,680 VA	5,000 VA	6,000 VA
EPS Load Overcurrent Protection	32 A		

13.6 Battery Pack

Battery specification			BP48100P1A-G2	BP48100PF1A-G2
normal	Battery capacity		5.12 kWh	
	Battery type		LFP	
	Rated voltage		51.2V	
	Operating voltage range		44.8–57.6V	
Operations	Maximum charging current		50A (0.5C)	
	Maximum discharging current		80A (0.8C)	
	Operating temperature range	Charge	0°C~+50°C	-10°C~+50°C
		Discharge	-10°C~+50°C	
	Storage temperature range		0°C~+35°C	
	Relative humidity		0%~95%(No condensation)	
	Protective class		I	
	Short circuit ratings		360A 300us	
BMS	Maximum number of butteries		Maximum 4 batteries in parallel	
	Monitored item		System voltage, current, battery voltage, battery temperature, PCBA temperature measurement	
	Communication mode		CAN	
	Ventilation mode		Passive and active cooling	
Physical parameters	Weight (kg)		50.5	
	Size (W×H×D) mm		725*165*370(Excluding handles)	
	Water resistance level		IP65	
Reference to standards			IEC 62619 IEC 62477 IEC 62040 IEC61000-6-1//3 UN38.3	

14 Abbreviations

A

AC	Alternating Current
AFCI	Arc-Fault Circuit-Interrupter
App	Application
AWG	American Wire Gauge

B

BESS	Battery Energy Storage System
BMS	Battery Management System

C

CT	Current Transformer
----	---------------------

D

DC	Direct Current
DOD	Depth of Discharge
DRED	Demand Response Enabling Device
DRM	Demand Response Mode
DSP	Digital Signal Processor

E

EMI	Electromagnetic Interference
EMS	Energy Management System
EPS	Emergency Power Supply

G

GFCI	Ground Fault Circuit Interrupter
------	----------------------------------

I

ISO	Insulation
-----	------------

M

MPPT	Maximum Power Point Tracker
------	-----------------------------

P

PV	Photovoltaic
----	--------------

R

RCD	Residual Current Device
RESP	Response
RRCR	Radio Ripple Control Receiver

S

SCI	Serial Communication Interface
SOC	State of Charge

15 Appendix: Definition of DVC

Decisive voltage Classification (DVC)	Limits of working voltage V		
	a.c. voltage r.m.s. U_{ACL}	a.c. voltage peak U_{ACPL}	d.c. voltage mean U_{DCL}
A*	25 (16)	35.4 (22.6)	60 (35)
B	50 (33)	71 (46.7)	120 (70)
C	> 50 (> 33)	> 71 (> 46.7)	> 120 (> 70)
The table values in parentheses are to be used for PCE or portions of PCEs rated for installation in wet locations as addressed in 6.1 for environmental categories and minimum environmental conditions. *DVC-A circuits are allowed under fault conditions to have voltages up to the DVC- B limits, for maximum 0.2 s.			