


EC15 - Easy Control

Example connection diagram



Jumper	Function
TERM	RS-485 - terminator 120 Ohm enabled (ON) / disable (OFF)

Default jumper placement is in bold.

Quick Start

1. Insert SIM card. PIN code request must be disabled.
2. Connect **5 VDC** power supply
3. Setup APN using SMS command: "**APN internet**" where "internet" is your SIM card provider APN.
4. Navigate to Rayleigh Connect: **www.raylightconnect.net** and register device using Serial Number and Registration Code.

Serial number

Registration code